

CD3018M CD3014M

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	26	PLANET GEAR2
2	CHUCK	27	MOVABLE GEAR
3	TORQUE BUSH	28	MIDDLE COVER
4	TORQUE RING	29	TAPPING SCREW
5	SPRING-REBOUND PLATE	30	2-SPEED STEEL WIRE
6	SCREW RING	31	GEAR
7	BIG SRPING	32	FIXED GEAR RING
8	CIRCLIP	33	PLANET GEAR1
9	WASHER	34	WASHER
10	STEEL BALL	35	SCREW
11	WASHER	36	SPRING WASHER
12	STOP PIN	37	MOTOR COVER
13	STEEL BALL	38	MOTOR GEAR
14	BUSH	39	MOTOR
15	GEAR BOX	40	2-SPEED LEVER
16	2-SPEED LOCK SHAFT	41	TAPPING SCREW
17	LOCK WASHER	42	LED LIGHT
18	LOCK PIN	45	F/R LEVER
19	LOCK RING	46	SWITCH
20	TRIANGLE BLOCK	47	CONNECTOR
21	PLANET BRACKET	63	QUICK CHARGER
22	INNER GEAR RING	100	BATTERY PACK
23	PLANET GEAR RING	101	GEAR BOX ASSEMBLY
24	BIG WASHER	888	HOUSING ASSEMBLY
25	2ND PLANET BRACKET		

ST20120614-01

