



CD3024C

NO.	DESCRIPTION	NO.	DESCRIPTION
1	TAPPING SCREW	21	GOVERNOR BOX
2	RINGHT ENCLOSURE	22	WASHER
3	SWITCHASS	23	PLANET GEAR
4	BATTERY PACK	24	SHAFT
5	INNER THCADCD RING	25	REMOVABLE GEAR RING
6	TOQURE ADJUSTING RING	26	LEVER
7	POSITING SPRING	27	PLANET BRACKET
8	COMPRESSING PLATE	28	PLANETARY GEAR
9	TAPPING SCREW	29	PLANET BRACKET
10	CHUCK	30	PLANET GEAR
11	CHUCK SCREW	31	FIXED GEAR RING
12	SPRING	32	WASHER
13	WASHER	33	MOTOR FLANGE
14	BALL GROUP	34	MOTOR
15	SNAP RING	35	LEFT ENCLOSURE
16	WASHER	36	DRIVER BIT
17	SMALL BALL GROUP	37	DECORATIVE PLATE
18	GEARING BOX	38	DIRECTION SETTING BUTTON
19	GEARING RING	39	SPEED SELECTOR BUTTON
20	SHAFT COAT		

RU5101201