

POWER • GAS • HAND • TOOLS

-	NO	DESCRIPTION	NO	DESCRIPTION
	NO.	DESCRIPTION	NO.	DESCRIPTION
	1	CHUCK SCREW	27	UPPER GEAR RING
	A2	CHUCK	28	THE FIRST PLANET CARRIER
	3	BIG CIRCLIP	29	THE FIRST PLANET GEAR
	4	TORQUE ADJUSTMENT PIECE	30	WASHER (R)
	5	TORQUE ADJUSTMENT RING	31	SCREW
	6	TORQUE ADJUSTMENT NUT	32	MOTOR COVER
	7	SPRING	33	MOTOR GEAR
	8	BIG WASHER	34	MOTOR
ı	9	PIN	35	TWO SPEED CHANGE BUTTON
	10	STEEL BALL	36	SPRING
	11	SPINDLEVER • GAS •	37	RIVET OOLS
	12	BEARING 689Z	39	DIRECTION CHANGLE LEVEL
	13	TORQUE ADJUSTMENT SPRING	40	SWITCH
	14	GEAR BOX	41	BATTERY CONNECTION FOOT
	15	TWO SPEED CHANGE SPRING	42	HOUSING BUCKLE
	16	GEAR BOX PIN	44	SCREW
	17	CRICLIP	45	BATTERY PACK
	19	INNER GEAR RING	46	CHARGER
_	20	THE THIRD PLANET CARRIER	47	SPINDLE LOCK RING
	21	THE THIRD PLANET GEAR	48	SPINDLE LOCK PIN
	22	WASHER	49	SPINDLE LOCK BLOCK
	23	THE SECOND PLANET CARRIER	50	O RING
	24	THE SECOND PLANET GEAR	100	GEAR BOX ASSEMBLY
	25	MOVING GEAR RING	101	MOTOR ASSEMBLY
	26	GEAR BOX BUSH	888	HOUSING ASSEMBLY

ST-UK20170712

