


BT8942D

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	GEAR CASE ASS'Y	31	HARNES CLAMP	61	SPRING
2	STOP RING	32	CLAMP	62	CLOCK PIN
3	STOP RING	33	SCREW M5X20	63	HANDGRIP
4	BEARING 6000-2RS/P5	34	NUT	64	SPRING
5	PINION	35	CLUTCH COMP.	65	BOX,RIGHT
6	STEEL PLATE CAP	36	CLUTCH DRUM COMP.	66	SCREW ST2.9X18
7	SCREW M6X20	37	STOP RING	67	SCREW M5X30
8	WASHER	38	BEARING 6202-2RS/P5	68	CABLE COMP.
9	SCREW M5X12	39	STOP RING	69	TUBE
10	BOLT M6X12	40	LINKER	70	STOP BUTTON COMP.
11	WASHER	41	RUBBER COVER	71	HANDGRIP
12	GEAR CASE	42	SCREW	72	SPRING
13	BLADE COVER	43	WASHER	73	BOX,LEFT
14	BEARING 6000/P5	44	WASHER	74	NYLON CUTTER HEAD
15	GEAR	45	CLAMP B	75	CASE
16	GEAR SHAFT	46	CLAMP A	76	LEFT NUT
17	BEARING 6002-2RS/P5	47	WIRE CLAMP BAND	77	WASHER
18	STOP RING	48	HARNES ASS'Y	78	SPRING
19	HOLDER	49	SCREW M5X2	79	NYLON CORD
20	HOLDER	50	CAP,LOWER	80	CORD HOLDER
21	WASHER	51	RUBBER WASHER	81	PLATEN
22	LEFT NUT	52	BRACKET	82	COVER
23	PIN	53	HANDLE	83	BRACKET
24	BLADE	54	GRIP LEFT	84	SCREW M5X30
25	PIPE COMP.	55	CAP,UPPER	85	SAFETY GUARD
26	RUBBER COVER	56	BOLT	86	SCREW M5X16
27	OIL-BEARING	57	HANDLE	87	SCREW ST4.2X16
28	DRIVE SHAFT	58	LEVER ASS'Y	88	GUARD
29	PIPE	59	SCREW ST2.9X13	89	BLADE
30	HOLDER ASSY	60	BUTTON	90	GUARD ASS'Y

RU61227-1

Sturm!
Germany



ENGINE FOR BT8942D

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	35	CORD COMP.	69	SCREW
2	WASHER	36	WASHER B	70	WASHER
3	START ROPE REEL	37	SPRING	71	CHOKE HANDLE
4	ROPE	38	EXPANDER	72	INSIDE COVER
5	RECOIL SPRING	39	WASHER	73	CHOKE
6	START COVER ASS'Y	40	SCREW PIN	74	BUFLER
7	START HANDLE	41	FAN COVER	75	WASHER
8	RING	42	BOLT	76	WASHER
9	SCREW	43	CLIP	77	SCREW
10	STAND	44	BEARING	78	FILTER NET
11	RUBBER COVER	45	RING	79	INSIDE COVER
12	GASKET	46	PISTON	80	O-WASHER
13	NUT	47	PISTON PIN	81	OUTSIDE COVER
14	START CLAW	48	BOLT	82	SCREW
15	START SPRING	49	PISTON RING	83	STARTER
16	START REEL	50	GASKET	84	CLEANER COVER
17	STOP RING	51	CYLINDER	85	FUEL PIPE
18	SEAL	52	SCREW	86	PLUG
19	CRANK CASE	53	GUIDE COVER ASS'Y	87	FUEL PIPE
20	GASKET	54	SPARK PLUG	88	FUEL TANK
21	BEARING 6202/P5	55	SPRING	89	STAND
22	CRANK SHAFT	56	PLUG CAP	90	FUEL TANK LID
23	KEY	57	CAP	91	GASKET
24	PIN	58	COVER	92	INLET
25	RUBBER WASHER	59	PLUG	93	INSIDE COVER
26	CRANK CASE	60	GASKET	94	INSIDE COVER
27	GUIDE COVER	61	MUFFLER	95	CHAIN
28	PIN	62	BOLT	96	SCREW
29	SEAL	63	NUT	97	OUTLET
30	SCREW	64	MUFFLER COVER	98	STOP RING
31	FLY WHEEL	65	GASKET	99	FUEL TANK LID COMP.
32	NUT	66	ADMITTING PIPE	100	FUEL TANK COMP.
33	COIL	67	GASKET	101	AIR FILTER
34	BOLT	68	CARBURETOR		

RU61231-2

Sturm!
Germany