


PG8722E

NO.	DESCRIPTION	NO.	DESCRIPTION
1	FUEL METER ASSY	42	BOTTOM RUBBER I
2	SCREW M5X6	43	FRAME
3	FUEL TANK CAP	44	FLANGE BOLT M6X12
4	FUEL TANK CAP SEAL	45	MUFFLER COVER
5	FUEL FILLER	49	ENGINE
6	FUEL TANK	50	CONTROL ASSY
7	BOLT M6X16	51	AIR CLEANER CASE COMP
8	TANK RUBBER	52	AIR CLEANER SEAL
9	FUEL COCK	53	SEPARATOR
10	FUEL LINE	54	ELEMENT
11	MUFFLER	55	AIR CLEANER COVER COMP
12	NUT M6	100	BATTERY SUPPORT
13	BOLT	101	BOLT
14	MUFFLER STAY ASSEMBLY	102	BATTERY
15	BRUSH ASSY	103	BATTERY SETTING PLATE
16	GENERATOR END COVER	104	JACKET
17	BOLT M5X10	105	BATTERY BLACK WIRE
18	BOLT M5X16	106	BATTERY RED WIRE
19	TERMINAL	107	NUT
20	EARTH BOLT	108	BOTTOM RUBBER II
21	AVR	109	STRAIGHT BOTTOM RUBBER
22	DIODE ASSY	110	EARTH LINE
23	END COVER	201	AC CIRCUIT BREAKER
24	FLANGE BOLT M6X130	202	DC CIRCUIT BREAKER
25	STATOR COVER	203	DIGITAL PANEL METER
26	STATOR ASSY	204	RECEPTACLE(DC)
27	FLANGE BOLT M8X210	205	CONTROL BOX
28	WASHER	206	PLASTIC SLEEVE
29	BEARING 6202	207	RIPPLE PIPE
30	ROTOR COMP	208	PLASTIC SLEEVE
31	COOLING FAN	209	2A BREAKER
32	CRANKCASE COVER	210	RECTIFIER
36	RECEPTACLE (AC)	301	AIR CLEANER ASSEMBLY(51+52+...55)
38	SWITCH		
39	CONTROL PANEL		
40	FRAME RUBBER		
41	NUT M8		



ENGINE FOR PG8722E

No.	DESCRIPTION	No.	DESCRIPTION	No.	DESCRIPTION
7	THROTTLE RETURN SPRING	47	GOVERNOR SHAFT WASHER	94	PUSH ROD
8	GOVERNOR SPRING	48	GOVERNOR COVER	95	KEY
9	GOVERNOR ARM	49	CRANKSHAFT COMP	100	MUFFLER PACKING
10	NUT M6	50	CASE OVER PACKING	101	STUD BOLT
11	LOCK PIN	51	OIL FILLER CAP ASSEMBLY	102	SHROUD COMP
12	GOVERNOR ARM SHAFT	52	OIL FILLER CAP PACKING	103	FIRST RING SET
13	GOVERNOR ROD	53	CRANKCASE COVER		SECOND RING SET
14	FLANGE BOLT M6X12	54	FLANGE BOLT M8X32		RING COMP
15	GOVERNOR ARM BOLT	55	FLANGE BOLT M6X8	104	PISTON
16	CONTROL ASSEMBLY	63	FLANGE BOLT M6X25	105	PISTON PIN CLIP
17	GOVERNOR WASHER	64	IGNITOR	106	PISTON PIN
18	RECOIL STARTER KNOB	65	DOWEL PIN 10*16	107	CONNECTING ROD COMP
19	RECOIL STARTER COMP	66	FLANGE BOLT 8*55	108	OIL FILLER CAP
20	RECOIL STARTER SPRING	67	CARBURETOR WASHER	109	FAN COVER COMP
21	RECOIL STARTER ROPE	68	CHOKE LEVEL COMP	110	CONTROL ON-OFF
22	RECOIL STARTER REEL	69	CARBURETOR ASSEMBLY	111	FLY WHEEL
23	RETURN SPRING	70	CARBURETOR PACKING	112	FLANGE BOLT M6*10
24	STARTER RATCHET	71	CARBURETOR INSULATOR	113	ELECTRIFY COIL
25	RATCHET GUIDE	72	INSULATOR PACKING	114	WIRE FLAT
26	SETTING SCREW	73	STUD BOLT 6*113	115	CONTROL ASSY
27	SWITCH	74	BREATHER TUBE	116	RELAY
28	FAN COVER COMP	75	HEAD OVER COMP	117	START MOTOR
29	NUT M14	76	HEAD OVER PACKING	201	STARTER ASSEMBLY(18+...26+55)
30	START HUB	77	VALVE ROTATOR		
31	COOLING FAN	78	INTAKE VALVE SPRING RETAINER		
32	FLY WHEEL	79	EXHAUST VALVE SPRING RETAINER		
33	SIDE PLACE	80	VALVE SPRING		
34	OIL SEAL	81	SPARK PLUG		
35	DIODE BASE COMP	82	CYLINDER HEAD COMP		
36	DIODE COMP	83	CYLINDER HEAD GASKET		
37	DRAIN PLUG BOLT	84	INTAKE VALVE		
38	DRAIN BOLT WASHER	85	EXHAUST VALVE		
39	CRANKCASE	86	VALVE LIFTER		
40	RADIAL BALL BEARING 6205	87	CAMSHAFT ASSEMBLY		
41	OIL LEVEL SWITCH ASSY	88	DOWEL PIN 8*14		
42	GOVERNOR WEIGHT HOLDER	89	PIVOT ADJUSTING NUT		
43	GOVERNOR WEIGHT PIN	90	ROCKER ARM PIVOT		
44	GOVERNOR SHAFT	91	VALVE ROCKER ARM		
45	GOVERNOR HOLDER CLIP	92	PIVOT BOLT		
46	GOVERNOR WEIGHT	93	PUSH ROD GUIDE PLATE		