



**CM1913B1, CM1913C1, CM1913CB1
CM1915C1, CM1917C1, CM1920C1, CM1912CB1**

NO.	DESCRIPTION	NO.	DESCRIPTION
1	FRONT STAND	37	SWITCH
2	BOLT	38	MOTOR
3	NUT	38-1	LEFT MOTOR HOLDER
4	WASHER	38-2	RIGHT MOTOR HOLDER
5	BOLT	38-3	BEARING 6203Z
6	CROSSBEAM	38-4	BOLT
7	NUT	38-5	FAN
8	HANDLE	38-6	ROTOR
9	BOLT	38-7	CAPACITOR HOLDER
10	NUT	38-8	CAPACITOR
11	BOLT	38-9	NUT
12	BOLT	38-10	STATOR
13	LOCKING PLATE	38-11	WASHER
14	BRACKET	39	BOLT
15	STAND TUBE	40	FIXED BRACKET
16	CIRCLIP	41	GLAND
17	BOTTOM DRUM	42	POWER CORD&PLUG
18	GEAR RING(EXCEPT CM1913B1)	43	CIRCLIP
19	RUBBER PILLOW	44	SMALL SHAFT
20	UPPER DRUM	45	PINION
21	MIXING BLADE	46	WASHER
22	BOLT	47	BOLT
23	BOLT	48	BOLT
24A	FIXED BOARD	49	UPPER COVER OF BEARING
25	BOLT	50	BEARING 6206Z
26	BELT WHEEL	51	SHAFT
27	BELT	52	BOTTOM COVER OF BEARING
28	BOLT	53	BOLT
29	BOLT	54	BEARING 6102Z
30	SUPPORT BRACKET	55	WASHER
31	NUT	56	BOLT
32	WASHER	57	WASHER
33	BIG WASHER	58	SPRING
34	WHEEL	59	CONNECTION BOARD(ONLY FOR CM1912CB1)
35	OPENING PIN	60	PRESS BOARD
36A	CONTROL BOX		

ST20120412-01