



## BC2455J

NO.	DESCRIPTION	NO.	DESCRIPTION
1	COVER OF WHEEL	46	CURRENT METER
2	CLIP FOR WHEEL	47	TAPING SCREW
3	WHEEL	48	FUSE
4	HEX BOLT	49	BOLT
5	SPRING WASHER	50	FLAT WASHER
6	FLAT WASHER	51	SPRING WASHER
7	AXIS OF WHEEL	52	NUT
8	FIXING PLATE FOR AXIS	53	FUSE COVER
9	BOTTOM CASE	54	BACK CASE
11	STEEL STAND	55	ANTI-PULL BLOCK
12	HEX BOLT	56	TAPING SCREW
13	SPRING WASHER	57	HEX BOLT
14	FLAT WASHER	58	FLAT WASHER
15	HEX BOLT	59	SPRING WASHER
16	FLAT WASHER	60	HEX BOLT
17	SPRING WASHER	61	CONNECT POT (FEMALE)
18	NUT	62	CONNECT POT (MALE)
19	U-TYPE CLIP	63	NUT
20	TRANSFORMER	64	FIXING KNOB OF CABLE
21	THERMAL CUT-OFF	65	OUTPUT CABLE
22	FIX PLATE FOR THERMAL CUT-OFF	66	CHARGING CLAMP
23	TAPING SCREW	67	OUTPUT CABLE
24	FRONT CASE	68	CHARGING CLAMP
25	ROUND SCREW	69	TIMER
26	FLAT WASHER	70	OFF/CHARGING/START TRANSFORM SWITCH
27	HANDLE	71	CURRENT TRANSFORM SWITCH
28	NUT	72	HEX BOLT
29	SPRING WASHER	73	FLAT WASHER
30	RECTIFIER	74	SPRING WASHER
31	SPRING WASHER	75	NUT
32	FLAT WASHER	76	NUT
33	HEX BOLT	77	SPRING WASHER
34	CURRENT DETECTOR	78	FLAT WASHER
35	ROUND BOLT	79	INSULATION WASHER
36	FLAT WASHER	80	INDICATOR LAMP
37	NUT	81	HEX BOLT
38	FIX PLATE FOR TIMER	82	FLAT WASHER
39	KNOB OF TIMER	83	HEX BOLT
41	OPERATION PANEL	84	POWER CABLE AND PLUG
42	NUT	101	TRANSFORMER ASSEMBLY (19+20+21+22)
43	SPRING WASHER	102	CHARGING CABLE AND CLAMP (RED)
44	FLAT WASHER	103	CHARGING CABLE AND CLAMP (BLACK)
45	FLAT BOLT		

ST20120620