



## SG9612

NO.	DESCRIPTION	NO.	DESCRIPTION
1	NOZZLE	16	BOARD SPRING
2	LOCK NUT	17	ADJUST POLE ASSEMBLY
3	VALVE	18	REGULATE KNOB
4	O-RING	19	SHOCK ABSORBER
5	CYLINDER	20	ACTIVE IRON
6	PISTON SPRING	21	RUBBER HEAD
7	PISTON	22	RIGHT HOUSING
8	LEFT HOUSING	23	TRIGGER
9	SCREW	24	SWITCH
10	DRIVER	25	TERMINAL BLOCK
11	DRIVER FIXED	26	PUMP HOUSING
12	DRIVER HOUSING	27	SUCTION TUBE
13	CORD BRACKET	28	CONTAINER
14	CORD SLEEVE	29	SCREW
15	CORD & PLUG	30	LABEL

RU080729-1