



MM1202

NO.	DESCRIPTION
1	UPPER CASE
2	CLAMP PART
3	FUNCTION SWITCH
4	LCD & LCD SOCKET
5	PCB
6	PRESS KEY
7	BOTTOM CASE
8	BATTERY
9	BATTERY COVER
10	SCREW

RU6011201