

CS50161

	NO.	DESCRIPTION	NO.	DESCRIPTION
	1	SOFT HANDLE COVER	35	FIXED GUARD
POWE	2	RIGHT HANDLE	36	RIVING KNIFE
	3	CORD & PLUG	37	HEX SCREW
	4	CORD SLEEVE	38	MOVING GUARD
	5	SCREW	39	BEARING 6001
	6	CORD ANCHORAGE	40	OUTPUT SHAFT
	7	CAPACITOR	41	WOODRUFF KEY
	8	SWITCH	42	BEARING COVER
	9	LEFT HANDLE	43	SCREW
	10	REAR COVER	44	INNER FLANGE
	11	DECORATED BOARD	45	SAW BLADE
	12	CARBON BRUSH	46	OUTER FLANGE
	13	BRUSH COPPER NEST	47	PLAIN WASHER
	14	BRUSH HOLDER	48	HEX SCREW
	15	SCREW	49	PULLING SPRING
	16	SPRING WASHER	50	SCREW
	17	HOUSING	51	SCREW
	18	ELECTRIC CONNECT PIECE	52	SCREW
	20A	STATOR	53	RUBBER BLOCK
	21	SCREW	54	CONNECTION SCREW
	22	WIND GUARD	55	KNOB FOR ANGLE ADJUSTMENT (I)
	23	BEARING 608	56	DEPTH STAND
	24A	ROTOR	57	SCREW
	25	BEARING 6000	58	BASE PLATE
	27	CENTRAL SUPPORTER	59	RIVET
	28	OILED BEARING	60	SCREW FOR FIXED PARALLEL GUIDE
	29	CIRCLIP	61	ANGLE STAND
	30	BIG GEAR	62	KNOB FOR ANGLE ADJUSTMENT (II)
	31	BEARING BASE	63	SCREW
	32	SPRING WASHER	64	SAFETY BLOCK
	33	SCREW	65	TAPPING SCREW
	34	KNOB FOR DEPTH ADJUSTMENT		

ST20130508-01

