



CS5020C

| NO. | DESCRIPTION | NO. | DESCRIPTION |
|-----|------------------------|-----|--------------------------|
| 1 | LEFT HANDLE | 38 | SCREW |
| 2 | SCREW | 39 | MOVING GUARD |
| 3 | SCREW | 40 | WASHER |
| 4 | CORD&PLUG | 41 | CIRCLIP |
| 5 | SCREW | 42 | BLADE |
| 6 | CORD SLEEVE | 43 | BEARING 6201 |
| 7 | SWITCH | 44 | CIRCLIP |
| 8 | CAPACITOR | 45 | MIDDLE COVER |
| 9 | SCREW | 46 | SCREW |
| 10 | RIGHT HANDLE | 47 | HEX BOLT |
| 11 | SCREW | 48 | WASHER |
| 12 | COVER | 49 | OUTER FLANGE |
| 13 | BEARING PRESSING SHEET | 50 | INNER FLANGE |
| 14 | ROTOR | 51 | PULL SPRING |
| 15 | BEARING 6201 | 52 | SCREW |
| 16 | WAVE WASHER | 53 | SPRING HOOK |
| 17 | WIND GUARD | 54 | FORE COVER |
| 18 | STATOR | 55 | HEX NUT |
| 19 | HOUSING | 56 | RIVING KNIFE |
| 20 | TWIST SPRING | 57 | TOP HANDLE |
| 21 | NUT | 58 | DOWN HANDLE |
| 22 | SCREW | 59 | HEX BOLT |
| 23 | BRUSH HOLDER | 60 | ANGLE ADJUSTMENT BRACKET |
| 24 | CARBON BRUSH | 61 | RIGHT BRACKET |
| 25 | SCREW | 62 | RETAINING RING |
| 26 | SCREW | 63 | HEX SCREW |
| 27 | REAR COVER | 64 | DEPTH ADJUSTMENT BRACKET |
| 28 | SCREW | 65 | LONG WING BOLT |
| 29 | OIL STORAGE RING | 66 | WING BOLT |
| 30 | GEAR BOX | 67 | LEFT BRACKET |
| 31 | BEARING 629 | 68 | RIVET |
| 32 | BIG GEAR | 69 | BASE PLATE |
| 33 | OUTPUT SHAFT | 70 | CONNECTION PIN |
| 34 | BEARING 6204 | 71 | TWIST WASHER |
| 35 | CIRCLIP | 72 | SCREW |
| 36 | SCREW | 73 | WASHER |
| 37 | FIXED GUARD | 74 | WING NUT |

RU70319-1