


## AW-97119X

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CONNECTOR	22	REACTANCE
2	SPRING WASHER	23	RADIATOR
3	BELT	24	NUT
4	NUT	25	SPRING WASHER
5	POTENTIOMETER	26	SUPPORT STAND FOR PCB
6	WHITE LAMP CAP	27	SUPPORT STAND FOR PCB
7	YELLOW LAMP CAP	28	INSULATION RING
8	BASE	29	ROUND SCREW
9	SCREW	30	CAPACITANCE
10	INSULATION BLOCK	31	RADIATOR FOR RECTIFIER
11	NUT	32	RADIATOR FOR IGBT
12	SWITCH	33	RADIATOR FOR IGBT
13	COOLING FAN	34	RE-ACTION DIOD
14	SCREW	35	IGBT
15	TRANSFORMER	36	UPPER PCB
16	NUT	37	SCREW
17	L-TYPE COPPER LINK	38	RELAY
18	NUT	39	POWER CORD
19	COVER	40	TAPING SCREW
20	BOTTOM PCB	41	HEAT PROTECTOR
21	FAST RECOVER DIOD		

BM20110810

# UPPER BOARD FOR AW-97119X



# DOWN BOARD FOR AW-97I19X

