


AW97CS30



NO.	DESCRIPTION	NO.	DESCRIPTION
1	COVER	38	FACEPLATE OF THE CHARGER
2	SPRING METAL PIECE	39	TIP FACEPLATE OF THE CHARGER
3	WHEEL	40	NUT
4	BOLT	41	WASHER
5	SPRING - WASHER	42	PROTECTIVE DEVICE
6	FLAT - WASHER	43	POWER ON/OFF SWITCH
7	SHAFT OF WHEEL	44	SWITCH
8	PLATE OF WHEEL SHAFT	45	HANDLE
9	SOLEPLATE OF THE CHARGER	46	NUT
10	UNDERPROP OF TRANSFORMER	47	SPRING - WASHER
11	SHELF	48	FLAT - WASHER
12	BOLT	49	BOLT
13	FLAT - WASHER	50	CURRENT METER
14	BOLT	51	FUSE
15	FLAT - WASHER	52	BOLT
16	SPRING - WASHER	53	FLAT - WASHER
17	NUT	54	WASHER
18	U-SHAPED FASTENER	55	NUT
19	TRANSFORMER	56	COVER OF FUSE
20	BOLT	57	LOCK SLEEVE OF CABLE
21	BACK PLATE	58	TAPPING SCREW
22	TAPPING SCREW	59	HEXAGONAL BOLT
23	THERMAL PROTECTIVE DEVICE	60	SPRING - WASHER
24	FIXITY	61	FLAT - WASHER
25	BOLT	62	HEXAGONAL NUT
26	FLAT - WASHER	63	SEAT OF BOLT LINKER
27	SPRING - WASHER	64	SEAT OF BOLT LINKER
28	NUT	65	NUT
29	RECTIFIER	66	KNOB
30	FIXITY	67	CABLE
31	NUT	68	CLIP OF BATTERY
32	DETECTOR OF CURRENT	69	PLUG
33	BOLT	70	POWER CABLE
34	FLAT - WASHER	71	CAPACITANCE
35	NUT	72	RESISTANCE
36	BOLT	73	CAPACITANCE
37	FLAT - WASHER		