



AG-9012X

NO.	DESCRIPTION	NO.	DESCRIPTION
1	OUTSIDER FLANGE	29	ROTOR WITH FAN
3	INNER FLANGE	31	BEARING 608Z
4	PRESSURED BOARD	32	BUSH
5	SCREW	33	STATOR
6	WHEEL GUARD	34	SCREW ST4X60
7	FRONT COVER	35	HOUSING
8	SCREW M4X16	36	BRUSH HOLDER
9	WOODRUFF KEY	37	CARBON BRUSH
10	SPINDLE	38	BRUSH CAP
11	CIRCLIP	39	SWITCH BUTTON
12	BEARING 6000Z	40	SWITCH HANDSPIKE
13	SCREW M4X10	41	SPRING
14	BEARING COVER	42	CAPACITOR
15	BIG GEAR	43	SWITCH
16	SELF-OIL BUSH	44	SCREW ST4X14
17	AUXILIARY HANDLE	45	SWITCH HOLDER
18	SCREW ST4X30	46	SCREW ST4X14
19	WASHER	47	SWITCH CAP
20	CIRCLIP	48	CORD CLAMP
21	LOCK SPRING	49	SCREW ST4X14
22	LOCK PIN	50	CORD & PLUG
23	GEAR BOX	51	CORD SLEEVE
24	PINION GEAR	52	NAME PLATE
25	BEARING 6000Z	53	REAR HOUSING
26	BEARING COVER	54	SCREW ST4X16
27	SCREW		
28	BAFFLE RING		

BM20110223