



## AG9012E

NO.	DESCRIPTION	NO.	DESCRIPTION
1	OUTER FLANGE	26	ROLLING BEARING 6000Z
2	GRINDING WHEEL	27	BEARING COVER
3	INNER FLANGE	28	ARMATURE
4	NUT	29	ROLLING BEARING 627Z
5	WHEEL COVER	30	BEARING BUSH
6	HEX SCREW	31	WIND GUARD
7	OUTPUT SPINDLE	32	SWITCH POLE
8	WOODRUFF KEY	33	TAPPING SCREW
9	SCREW	34	STATOR
10	SPRING WASHER	35	SWITCH BUTTON
11	PLAIN WASHER	36	HOUSE
12	FORE COVER	37	TAPPING SCREW
13	ROLLING BEARING 6201Z	38	CARBON BRUSH HOLDER
14	BEARING COVER	39	CARBON BRUSH
15	PLAIN HEAD SCREW	40	CAPACITOR
16	BIG GEAR	41	SWITCH
17	CIRCLIP FOR SHAFT	42	CABLE ANCHORAGE
18	OGALLAY BEARING	43	SCREW
19	CIRCLIP FOR LOCKING PIN	44	VARIABLE SPEED CIRCUIT
20	SIDE HANDLE	45	SCREW
21	GEAR BOX	46	TRADE MARK
22	TAPPING SCREW	47	BACK COVER
23	SELF-LOCKING PIN	48	CABLE SLEEVE
24	SELF-LOCKING SPRING	49	CABLE
25	PINION GEAR	50	SPANNER