



AG9012S

NO.	DESCRIPTION	NO.	DESCRIPTION
1	OUTER FLANGE	2627	ROLLING BEARING 6000Z
2	GRINDING WHEEL	28	BEARING COVER
3	INNER FLANGE	29	ARMATURE
4	NUT	30	ROLLING BEARING 627Z
5	WHEEL COVER	31	BEARING BUSH
6	HEX SCREW	32	WIND GUARD
7	OUTPUT SPINDLE	33	SWITCH POLE
8	WOODRUFF KEY	34	TAPPING SCREW
9	SCREW	35	STATOR
10	SPRING WASHER	36	SWITCH BUTTON
11	PLAIN WASHER	37	HOUSE
12	FORE COVER	38	TAPPING SCREW
13	ROLLING BEARING 6201Z	39	CARBON BRUSH HOLDER
14	BEARING COVER	40	CARBON BRUSH
15	PLAIN HEAD SCREW	41	CAPACITOR
16	BIG GEAR	42	SWITCH
17	CIRCLIP FOR SHAFT	43	CABLE ANCHORAGE
18	OGALLAY BEARING	44	SCREW
19	CIRCLIP FOR LOCKING PIN	45	VARIABLE SPEED CIRCUIT
20	SIDE HANDLE	46	SCREW
21	GEAR BOX	47	TRADE MARK
22	TAPPING SCREW	48	BACK COVER
23	SELF-LOCKING PIN	49	CABLE SLEEVE
24	SELF-LOCKING SPRING	50	CABLE
25	PINION GEAR		SPANNER

RU59901