



AG9012V

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SPECIAL SPANNER	27	PRESS SHEET
2	OUTER FLANGE	28	WOODRUFF KEY
3	DEPRESSED CENTER DISC	29	SCREW
4	INNER FLANGE	30	ROTOR
5	SCREW	31	WIND GUARD
6	SPRING WASHER	32	BEARING 608Z
7	PRESS PLATE OF GUARD	33	BEARING COVER
8	GUARD	34	SCREW
9	SPINDLE	35	STATOR
10	WOODRUFF KEY	36	INDUCTANCE
11	SCREW	38	HOUSING
12	SPRING WASHER	39	NAMEPLATE
13	FRONT COVER	40	BUFF
14	BEARING 6201Z	41	BRUSH HOLDER
15	CHECK RING	42	CARBON BRUSH
16	LARGE BEVEL GEAR	43	SCREW
17	CHECK RING	44	SCREW
18	BUSH	45	ADJUST-SPEED SWITCH
19	SIDE HANDLE	46	CAPACITOR
20	SCREW	47	SWITCH
21	LOCK PIN	49	SCREW
22	SPRING	50	CORD CLAMP
23	CHECK RING	51	CORD SLEEVE
24	GEAR BOX	52	POWER CORD
25	SMALL BEVEL GEAR	888	HANDLE ASSEMBLE
26	BEARING 6000Z		

ST20101207-01