



## AG9015

NO.	DESCRIPTION	NO.	DESCRIPTION
1	BEARING BASE	27	CORD&PLUG
2	BEARING	28	REAR COVER
3	ROTOR	29	SCREW
4	CIRCLIP	30	CARBON BRUSH
5	BEARING COVER	31	BRUSH HOLDER
6	BEARING	32	HOUSING
7	LOCK PIN	33	ROLLER
8	SPRING	34	SCREW
9	CIRCLIP	35	STATOR
10	SCREW	36	SIDE HANDLE
11	GEAR BOX	37	WIND GUARD
12	BUSH	38	PINION GEAR
13	SPRING RING	39	SPRING WASHER
14	WASHER	40	NUT
15	GEAR	41	CORD CLAMP
16	BEARING COVER	42	SCREW
17	BEARING	43	KEY
18	FRONT COVER	44	SPINDLE
19	SPRING WASHER	45	INNER FLANGE
20	SCREW	46	OUTER FLANGE
21	PROTECTING COVER	47	SWITCH
22	BOLT	48	CAPACITOR
23	NUT	49	SPRING
24	SCREW	50	SWITCH DRAW-BAR
25	CORD SLEEVE	51	SWITCH KNOB
26	SCREW	52	SCREW

RU5111101