



AG90181

NO.	DESCRIPTION	NO.	DESCRIPTION
1	OUTER FLANGE	31	SCREW
2	GRINDING WHEEL	32	ARMATURE
3	INNER FLANGE	33	WIND GUARD
4	WHEEL COVER	34	SCREW
5	NUT	35	STATOR
6	SCREW	36	LINK SPRING
7	WOODRUFF KEY	37	BEARING 629Z
8	OUTPUT SPINDLE	38	BEARING BUSHING
9	SCREW	39	HOUSING
10	SPRING WASHER	40	NAME PLATE
11	PLAIN WASHER	41	TRADE MARK
12	FORE COVER	42	BRUSH HOLDER
13	BEARING 6202Z	43	CARBON BRUSH
14	BEARING COVER	44	BRUSH HOLDER CAP
15	PLAIN WASHER	46	TAPPING SCREW
16	SPRING WASHER	47	TAPPING SCREW
17	SCREW	48	SOFT START
18	BIG GEAR	51	SWITCH
19	CIRCLIP FOR SHAFT	53	SCREW
20	OGALLAY BEARING	54	CABLE CLIP
21	CIRCLIP FOR LOCKING PIN	55	CABLE SLEEVE
22	TAPPING SCREW	56	CABLE
23	LOCKING PIN	57	INDUCTOR
24	BREAK SPRING	58	CAPACITOR
25	GEAR BOX	59	SIDE HANDLE
26	NUT	60	SPANNER
28	PINION GEAR	888	HANDLE ASSEMBLY
29	BEARING 6001Z		
30	BEARING COVER		

ST20110829-01

