



AG9025E

NO.	DESCRIPTION	NO.	DESCRIPTION
1	BEARING BASE	29	BRUSH HOLDER
2	BEARING	30	ROLLER
3	ROTOR	31	SCREW
4	CIRCLIP	32	LOCKING WASHER
5	BEARING COVER	33	HOUSING
6	BEARING	34	STATOR
7	LOCK PIN	35	SIDE HANDLE
8	SPRING	36	PINION GEAR
9	CIRCLIP	37	SPRING WASHER
10	SCREW	38	NUT
11	GEAR BOX	39	SCREW
12	BUSH	40	WIND GUARD
13	SPRING RING	41	CORD CLAMP
14	GEAR	42	SCREW
15	BEARING COVER	43	SCREW
16	BEARING	44	RIGHT HANDLE
17	FRONT COVER	45	SCREW
18	SPRING WASHER	46	SCREW
19	SCREW	47	SWITCH
20	PROTECTING COVER	48	TRIGGER
21	BOLT	49	CAPACITOR
22	NUT	50	NAME PLATE
23	CORD SLEEVE	51	KEY
24	CORD&PLUG	52	SPINDLE
25	SOFT COVER	53	INNER FLANGE
26	LEFT HANDLE	54	OUTER FLANGE
27	SCREW	55	SCREW
28	CARBON BRUSH	56	PCB

RU5111101