



AG9512H

NO.	DESCRIPTION	NO.	DESCRIPTION
1	OUTSIDE FLANGE	26	SCREW M4X10
2	INNER FLANGE	27	ARMATURE
3	SCREW M4X8	28	BEARING
4	SPRING WASHER	29	RUBBER BUSH
5	PRESSURED BOARD	30	FAN GUIDE
6	PROTECTIVE GUARD	31	SCREW M4X65
7	WOODRUFF KEY 3X3.7X10	32	STATOR
8	OUTPUT SPINDLE	33	RIVET3X8
9	SCREW M4X14	34	CARBON BRUSH
10	FORE COVER	35	BRUSH HOLDER
11	BEARING	36	PLASTIC HOUSING
12	BEARING COVER	37	CAPACITOR
13	SCREW M4X10	38	LINK POLE
14	BIG GEAR	39	BACK HOUSING
15	CIRCLIP FOR SHAFT 10	40	SCREW ST4.2X20
16	BUSH	41	NAME PLATE
17	GEAR BOX	42	CABLE PLUG
18	SCREW ST4.2X20	43	RUBBER SLEEVE
19	"E"RING 6	44	SPRING
20	SPRING	45	CORD CLIP
21	BRAKE PIN	46	SCREW ST4.2X13
22	SIDE HANDLE	47	SWITCH
23	SMALL GEAR	48	TRIGGER
24	BEARING	501	SPANNER
25	BEARING COVER	502	DISC

RU080820-1