



## OS8160R

NO.	DESCRIPTION	NO.	DESCRIPTION
1	HOUSING	20	BEARING 608Z
2	CORD & PLUG	21	MOTOR COVER
3	SCREW	22	NUT
4	CORD CLAMP	23	SCREW
5	SWITCH TRIGGER	24	HOUSING
6	SWITCH	25	PLASTIC GUARD
7	TERMINALBLOCK	26	BUSH
8	PCB	27	SCREW
9	SCREW	28	STEEL RING
10	CAPACITOR COVER	29	COUNTER WEIGHT
11	INDUCTOR	30	BEARING 60005RS
12	SCREW	31	WASHING
13	CAPACITOR	32	SCREW
14	MOTOR COVER	33	PAD HOLDING
15	CARBON BRUSH	34	PAD
16	BEARING 608Z	35	PAD
17	SLEEVE	36	PLASTIC PLATE
18	STATOR	37	SCREW
19	ROTOR		

RU20100101