


PG-8720X、PG-8725X、PG-8730X、PG-8730XE

NO.	DECRPTION	MATERIAL Nr.				NO.	DECRPTION	MATERIAL Nr.				NO.	DECRPTION	MATERIAL Nr.			
		PG-8720X	PG-8725X	PG-8730X	PG-8730XE			PG-8720X	PG-8725X	PG-8730X	PG-8730XE			PG-8720X	PG-8725X	PG-8730X	PG-8730XE
1	SCREW M5×10	PG0001				27	SPRING WASHER Φ6	PGE0027				54	VOLT METER	PG0054			
2	FUEL METER ASSY	PG0002				28	WASHER Φ6	PG0028				55	RED POSITIVE TERMINAL	PG0055			
3	FUEL TANK CAP	PG0003				29	END COVER	PG0029					BLACK NEGATIVE TERMINAL				
4	PLATE PINCH	PG0004				30	STATOR COVER	PG0030A	PG0030B	PG0030C	56	AC CIRCUIT BREAKERS	PG0056A	PG0056B	PG0056C		
5	FUEL FILTER	PG0005				31	STATOR ASSY	PG0031A	PG0031B	PG0031C	57	AC RECEPTACLE	PG0057				
6	FLANGE BOLT M6×20	PG0006				32	FLANGE BOLT M8×208	PG0032A	PG0032B	PG0032C	58	DC.10A CIRCUIT BREAKERS	PG0058				
7	WASHER Φ6.5	PG0007				33	SPRING WASHER Φ8	PG0033				59	BOLT M6×22	PG0059			
8	TANK RUBBER	PG0008				34	WASHER Φ8	PG0034				60	NUT M6	PG0060			
9	FUEL TANK	PG0009				35	ROTOR COMP	PG0035A	PG0035B	PG0035C	61	FRAME	PG0061A	PG0061B	PG0061C		
10	FUEL COCK	PG0010				36	ENGINE	PG0036A	PG0036B	PG0036C	62	STRAIGHT BOTTOM RUBBER	PG0062				
11	FUEL LINE	PG0011				37	SPRING WASHER Φ8	PG0037				63	BIG WASHER Φ8	PG0063			
12	CLIP	PG0012				38	AIR CLEANER STAY	PG0038				64	FLANGE BOLT M8×35	PG0064			
13	FLANGE BOLT M6×12	PG0013				39	FLANGE BOLT M6×8	PG0039				65	NUT M8	PG0065			
14	FLANGE BOLT M8×20	PG0014				40	MUFFLER GASKET	PG0040				66	BOTTOM RUBBER I	PG0066			
15	MUFFLER STAY (II)	PG0015				41	WASHER Φ8	PG0041				67	BOTTOM RUBBER II	PG0067			
16	MUFFLER STAY (I)	PG0016				42	NUT M8	PG0042				68	EARTH LINE	PG0068			
17	TERMINAL	PG0017				43	MUFFLER	PG0043A	PG0043B	PG0043C	69	NUT M6	PG0069				
18	FLANGE BOLT M5×12	PG0018				44	MUFFLER COVER	PG0044				BELOW FOR PG-8730XE					
19	GENERATOR END COVER	PG0019				45	RECTIFIER	PG0045				51	CIRCUIT BREAKERS	PG0051			
20	FLANGE BOLT M5×16	PG0020				46	FUSE(10A)	PG0046				101	JACKET	PG0101			
21	AVR	PG0021				47	CONTROL BOX	PG0047				102	BATTERY BLACK WIRE(-)	PG0102			
22	SPRING WASHER Φ5	PG0022				48	BUILD UP	PG0048				103	BATTERY RED WIRE(+)	PG0103			
23	WASHER Φ5	PG0023				49	CONDUIT	PG0049				104	BATTERY SUPPORT	PG0104			
24	DIODE ASSY	PG0024				50	BUILD UP	PG0050				105	FLANGE BOLT M8×40	PG0105			
25	BRUSH ASSY	PG0025				52	SWITCH	PG0052				106	BATTERY	PG0106			
26	FLANGE BOLT M6×133	PG0026A	PG0026B	PG0026C	53	CONTROL PANEL	PG0053				107	BATTERY SETTING PALTE	PG0107				



Engine for PG-8720X、PG-8725X、PG-8730X、PG-8730XE

No.	DESCRIPTION	MATERIAL Nr.		No.	DESCRIPTION	MATERIAL Nr.		No.	DESCRIPTION	MATERIAL Nr.	
		PG-8720X PG-8725X	PG-8730X PG-8730XE			PG-8720X PG-8725X	PG-8730X PG-8730XE			PG-8720X PG-8725X	PG-8730X PG-8730XE
1	THROTTLE RETURN SPRING	PGE0001		41	GOVERNOR SHAFT WASHER	PGE0041		81	PUSH ROD	PGE0081A	PGE0081B
2	GOVERNOR SPRING	PGE0002		42	GOVERNOR COVER	PGE0042		82	KEY	PGE0082	
3	GOVERNOR ARM	PGE0003		43	CRANKSHAFT COMP	PGE0043A	PGE0043B	83	MUFFLER GASKET	PGE0083	
4	NUT M6	PGE0004		44	CASE OVER GASKET	PGE0044		84	STUD BOLT	PGE0084	
5	LOCK PIN	PGE0005		45	OIL FILLER CAP ASSEMBLY	PGE0045		85	SHROUD COMP	PGE0085	
6	GOVERNOR ARM SHAFT	PGE0006		46	OIL FILLER CAP GASKET	PGE0046		86	FIRST RING SET	PGE0086	
7	GOVERNOR ROD	PGE0007		47	CRANKCASE COVER	PGE0047			SECOND RING SET		
8	FLANGE BOLT M6X12	PGE0008		48	FLANGE BOLT M8X28	PGE0048			RING COMP		
9	GOVERNOR ARM BOLT	PGE0009		49	FLANGE BOLT M6X8	PGE0049		87	PISTON	PGE0087A	PGE0087B
10	CONTROL ASSEMBLY	PGE0010		50	FLANGE BOLT M6X25	PGE0050		88	PISTON PIN CLIP	PGE0088	
11	GOVERNOR WASHER	PGE0011		51	IGNITOR	PGE0051		89	PISTON PIN	PGE0089	
12	RECOIL STARTER KNOB	PGE0012		52	DOWEL PIN 10*16	PGE0052		90	CONNECTING ROD COMP	PGE0090	
13	RECOIL STARTER COMP	PGE0013		53	FLANGE BOLT 8*55	PGE0053		91	OIL FILLER CAP	PGE0091	
14	RECOIL STARTER SPRING	PGE0014		54	CARBURETOR WASHER	PGE0054		92	AIR CLEANER COVER	PGE0092	
15	RECOIL STARTER ROPE	PGE0015		55	CHOKE LEVEL COMP	PGE0055		93	AIR CLEANER ELEMENT	PGE0093	
16	RECOIL STARTER REEL	PGE0016		56	CARBURETOR ASSEMBLY	PGE0056A	PGE0056B	94	AIR CLEANER GRID	PGE0094	
17	RETURN SPRING	PGE0017		57	CARBURETOR GASKET	PGE0057		95	AIR CLEANER BRACKET	PGE0095	
18	STARTER RATCHET	PGE0018		58	CARBURETOR INSULATOR	PGE0058		96	AIR CLEANER BACK PLATE	PGE0096	
19	RATCHET GUIDE	PGE0019		59	INSULATOR GASKET	PGE0059			BELOW FOR PG-8730XE		
20	SETTING SCREW	PGE0020		60	STUD BOLT 6*113	PGE0060		101	FAN COVER COMP	PGE0101	
21	SWITCH	PGE0021		61	BREATHER TUBE	PGE0061		102	FLY WHEEL	PGE0102	
22	FAN COVER COMP	PGE0022		62	HEAD OVER COMP	PGE0062		103	FLANGE BOLT M6*10	PGE0103	
23	NUT M14	PGE0023		63	HEAD OVER GASKET	PGE0063		104	ELECTRIFG COIL	PGE0104	
24	START HUB	PGE0024A	PGE0024B	64	VALVE ROTATOR	PGE0064		105	WIRE FLAT	PGE0105	
25	COOLING FAN	PGE0025		65	INTAKE VALVE SPRING RETAINER	PGE0065		106	SIDE PLACE	PGE0106	
26	FLY WHEEL	PGE0026		66	EXHAUST VALVE SPRING RETAINER	PGE0066		107	RELAY	PGE0107	
27	SIDE PLACE	PGE0027		67	VALVE SPRING	PGE0067		108	START MOTOR	PGE0108	
28	OIL SEAL	PGE0028		68	SPARK PLUG	PGE0068					
29	DIODE BASE COMP	PGE0029		69	CYLINDER HEAD COMP	PGE0069A	PGE0069B				
30	DIODE COMP	PGE0030		70	CYLINDER HEAD GASKET	PGE0070A	PGE0070B				
31	DRAIN PLUG BOLT	PGE0031		71	INTAKE VALVE	PGE0071					
32	DRAIN BOLT WASHER	PGE0032		72	EXHAUST VALVE	PGE0072					
33	CRANKCASE	PGE0033A	PGE0033B	73	VALVE LIFTER	PGE0073A	PGE0073B				
34	RADIAL BALL BEARING 6205	PGE0034		74	CAMSHAFT ASSEMBLY	PGE0074A	PGE0074B				
35	OIL LEVEL SWITCH ASSY	PGE0035		75	DOWEL PIN 8*14	PGE0075					
36	GOVERNOR WEIGHT HOLDER	PGE0036		76	PIVOT ADJUSTING NUT	PGE0076					
37	GOVERNOR WEIGHT PIN	PGE0037		77	ROCKER ARM PIVOT	PGE0077					
38	GOVERNOR SHAFT	PGE0038		78	VALVE ROCKER ARM	PGE0078					
39	GOVERNOR HOLDER CLIP	PGE0039		79	PIVOT BOLT	PGE0079					
40	GOVERNOR WEIGHT	PGE0040		80	PUSH ROD GUIDE PLATE	PGE0080					