



RH-2550

NO.	DESCRIPTION	NO.	DESCRIPTION
1	PROTECTIVE CAP	41	TOOTHED SHAFT
2	RETAINING RING 19X2	42	COMPRESSION SPRING
3	PROTECTION SLEEVE	43	PIN
4	THRUST RING	44	WASHER
5	HOLDING PLATE	45	NEEDLE BEARING AXK0614
6	BALL C7.14	46	BALL BEARING 609-2RS
7	SPRING	47	ROTOR
8	SCREW ST4.8X57.5	48	BALL BEARING 607-2RS
9	GEAR HOUSING	49	AIR-DEFLECTOR RING
10	NEEDLE BEARING HK0608	50	SCREW ST4X10
11	OIL SEAL 27.3X37X7	51	STATOR
12	NEEDLE ROLLER BEARING	52	RUBBER BEARING SLEEVE
13	NEEDLE BEARING HK3012	53	MOTOR HOUSING
14	O-RING 5X2.5	54	BRUSH HOLDER
15	SELECTOR KNOB	55	CARBON BRUSH
16	RETAINING RING 29X2.5	56	SCREW ST3X8
17	SUPPORTING DISC	57	INDUCTOR
18	COMPRESSION SPRING	58	CONNECTING CABLE 150MM
19	CYLINDRICAL GEAR	59	CONNECTING CABLE 60MM
20	RATCHET SLEEVE	60	HANGING BOARD
21	IMPACT BOLT	61	HOUSING COVER
22	GUIDE BUSHING	62	SCREW ST4.2X19
23	O-RING 18X3	63	SCREW ST4.2X16
24	O-RING 9.8X3.5	64	SWITCH
25	DAMPING BUSHING	65	CAPACITOR
26	RETAINING RING 26.5X2	66	SCREW ST4X16
27	STRIKER	67	CORD CLAMP
28	O-RING 14X3	68	CORD
29	PISTON	69	CORD GUARD
30	SHIM RING	70	WINGED SCREW
31	O-RING	71	CLAMP HOLDER
32	BUSHING	72	SUPPORT BLOC
33	INTERMEDIATE FLANGE	73	NUT
34	O-RING 23.2X2.4	74	AUXILIARY HANDLE
35	SPRING CLIP	75	CLAMPING BAND
36	BALL C5	76	T-BOLT
37	PISTON PIN	77	NUT
38	BALL BEARING 608-2RS	78	DEPTH GAUGE
39	CYLINDRICAL GEAR	999	AUXILIARY HANDLE
40	DRIVER END SHIELD		