



P-1010

NO	DESCRIPTION	NO	DESCRIPTION
1	adjustment cover	27	copper bush holder
2	screw ST4X16	28	carbon brush
3	adjustment knob	29	rotor
4	dial	30	bearing 608Z
5	connecting rod	31	bearing press board
6	screw M6X10	32	screw ST4X8
7	threaded rod	33	bearing 608Z
8	front base	34	blade holder
9	capacitor	35	bearing 6000Z
10	switch	36	bearing press board
11	soft handle cover	37	screw ST4X8
12	inductor	38	housing
13	carbon brush cover	40	screw ST4X20
14	screw ST4X16	41	small belt wheel
15	screw ST4X16	42	big belt wheel
16	cord clamp	43	nut M8
17	cord sleeve	44	belt
18	cord	45	belt cover
20	screw ST4X16	46	screw ST4X16
21	back base	47	lock knob
22	stator	48	supporting
23	screw ST4X55	49	parallel guide
24	wind guide	50	wrench
25	bearing 626z	51	dut bag
26	brush holder		