



GT-3510X

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	37	TAPPING SCREW	74	HEX BOLT
2	TUBE CONNECTOR	38	LABEL	75	PINION
3	KNOB	39	TAPPING SCREW	76	INPUT SHAFT
4	RIVET	41	SCREW	77	BEARING 609(2 PCS)
5	CONNECTOR WITH BEARING 609	42	AUXILIARY HANDLE	78	CIRCLIP FOR SHAFT
6	INSERT BUSH	43	KNOB	79	CIRCLIP FOR HOLE
7	SCREW	44	HEX. BOLT	80	SOFT SHAFT
8	SUPPORT	45	SWITCH	81	SOFT SHAFT SUPPORT
9	SOFT SHAFT	46	SPRING	82	SCREW
10	ALU.TUBE	47	BOUTTON	83	PRESSURE BOARD
11	RUBBER LINER	48	CAPACITOR	84	ALU.TUBE
12	HOUSING	49	TAPPING SCREW	85	TAPPING SCREW
13	LABEL	50	CORD ANCHORAGE	86	INSERT TUBE
14	SCREW	51	CORD GUARD	87	ALU.TUBE CAP
15	BRACKET	52	POWER CORD AND PLUG	88	LINE SPOOL GUARD
16	SCREW	53	SCREW	89	SMALL KNIFE
17	HOOK	54	SPRING WASHER	90	TAPPING SCREW
18	BELT	55	FLAT WASHER	91	KNIFE GUARD
19	SHAFT CONNECTOR	56	SPLINE BUSH	92	LINE BOX
20	BRUSH HOLDER	57	PRESSURE BOARD	93	HOLE-PROTECTING COIN
21	FRONT COVER	58	BLADE	94	CONNECT BOLT
22	CARBON BRUSH	59	PRESSURE BOARD	95	SPRING
23	BRUSH SUPPORT	60	CIRCLIP FOR HOLE	96	NYLON LINE
24	FLAT WASHER	61	BEARING 6001	97	BOBBIN
25	SPRING WASHER	62	WOODRUFF KEY	98	SPOOL COVER
26	SCREW	63	OUTPUT SHAFT	99	SOCKET WRENCH
27	BEARING 608	64	BIG GEAR	100	BAR
28	ROTOR	65	BEARING 608	101	CIRCLIP
29	STATOR	66	HEX. NUT	102	CIRCLIP
30	SCREW	67	BLADE GUARD	997	MOTOR ASSEMBLY(21+27+28...+35)
31	BEARING 608	68	GEAR BOX	998	LINE SPOOL ASSEMBLY(92+93...+98)
32	FLAT WASHER	69	FLAT WASHER	999	GEAR BOX ASSEMBLY(60+61...+66+68...+79)
33	SPRING WASHER	70	SPRING WASHER		
34	REAR COVER	71	HEX. BOLT		
35	FAN	72	SCREW		
36	PCB	73	SCREW		