



BGM6012L BGM6015L

| NO. | DESCRIPTION | NO. | DESCRIPTION |
|-----|-------------------|------|-------------------|
| 1 | GRINDER WHEEL | 30 | BOLT |
| 2 | BOLT | 31 | SWITCH |
| 3 | BOLT | 33 | RUBBER FEET |
| 4 | WASHER | 34 | BASE PLATE |
| 5 | EYESHIELD BRACKET | 35 | BOLT |
| 6 | WASHER | 36 | WASHER |
| 7 | SCREW | 37 | CAPACITOR |
| 8 | EYESHIELD | 39 | BOLT |
| 9 | BEARING 6002 | 40 | CABLE & PLUG |
| 10A | ROTOR | 41 | LEFT OUTER GUARD |
| 11 | STATOR | 42 | NUT |
| 13 | NAMEPLATE | 43 | LEFT INNER GUARD |
| 14 | MIDDLE RING | 44 | LEFT TOOL REST |
| 15 | COVER | 45 | BOLT |
| 16 | RIGHT INNER GUARD | 46 | CABLE ADAPTOR |
| 17 | MIDDLE RING | 47 | BASE |
| 18A | WHEEL FLANGE | 100 | CABLE PLATE |
| 19 | GRINDER WHEEL | 101 | CABLE CLIP |
| 20 | SCREW | 102 | SCREW |
| 21 | RIGHT OUTER GUARD | 103 | GROUND TERMINAL |
| 22 | BOLT | 104 | WASHER |
| 23 | SQUARE NECK SCREW | 105 | SCREW |
| 24 | WASHER | 107A | LAMP SWITCH |
| 25 | RIGHT TOOL REST | 108 | NUT |
| 26 | WASHER | 109 | WASHER |
| 27 | WASHER | 110 | LAMP |
| 28 | WORK HANDLE | 111 | CIRCLIP FOR SHAFT |
| 29 | BOLT | | |

BGM6012L BGM6015L-EX-UKW230809

