



БЕНЗОДВИГАТЕЛЬ ДЛЯ BPM8752



NO.	DESCRIPTION	NO.	DESCRIPTION
A-1	CRANKSHAFT ASSY	D-1	GASKET
A-2	KEY	D-2	CYLINDER
A-3	PISTON RING	D-3	SPARK PLUG
A-4	PISTON	D-4	SCREW
A-5	PISTON PIN RING	D-5	SCREW
A-6	BEARING	D-6	ENGINE COVER
A-7	PISTON	D-7	SCREW
B-1	CRANKSHAFT CASE	D-8	TOP COVER
B-2	BEARING6202	D-9	SCREW
B-3	OIL SEAL	D-10	SHIM
B-4	PIN	D-11	SCREW
B-5	SCREW	D-12	WIND SCREEN
B-6	FLYING WHEEL	E-1	GASKET
B-7	NUT	E-2	MUFFLER
B-8	SCREW	E-3	SCREW
B-9	COIL	E-4	SCREW
B-10	SPARK PLUG CAP	F-1	GASKET
B-11	OFF LINE	F-2	INLET PIPE
B-12	OFF LINE	F-3	SCREW
B-13	SHIM	F-4	GASKET
B-14	CLUTCH ASSY	F-5	CARBURETOR
B-15	SHIM	F-6	CARBURETOR HOLDER
B-16	SCREW	F-7	SCREW
B-17	SIDE COVER	F-8	SPONGE
B-18	SCREW	F-9	SPONGE COVER
C-1	CRANKSHAFT CASE	F-10	AIR FILTER COVER
C-2	BEARING6202	F-11	NUT
C-3	PIN	G-1	TANK CAP
C-4	GASKET	G-2	TANK HOLDER
C-5	OIL SEAL	G-3	SCREW
C-6	DRIVING PLATE	G-4	DAMPING
C-7	NUT	G-5	TANK PROTECTOR
C-8	STARTER ASSY	G-6	TANK
C-9	SCREW		

BPM8752-EX-UK251217-2

BPM8752



NO.	DESCRIPTION
1	ENGINE ASSY
2	PASSIVE DISK
3	CIRCLIPS
4	BEARING6202
5	CLUTCH CASE
6	CIRCLIPS
7	SCREW
8	NUT
9	HANDLE
10	PUMP CASING COVER
11	WATER SEAL
12	IMPELLER(SMALL)
13	IMPELLER(BIG)
14	SEAL RING4*50
15	SEAL RING3.5*165
16	PUMP CASE
17	SCREW
18	WASHER
19	CONNECTION BASE
20	SCREW
21	SEAL RING
22	INLET/OUTLET PIPES
23	LOCKER
24	WATER STOPPER
25	SEAL RING
26	SCREW
27	WASHER
28	CONNECTION BASE
29	SCREW
30	RUBBER MAT
31	SCREW
32	SCREW
33	PUMP BASE
34	SREW
35	SWITCH ASSY
36	WATER FILTER
37	SLEEVE
38	CLAMP