


# CSM50191



NO.	DESCRIPTION	NO.	DESCRIPTION
1	BOLT M8×14	36	MOTOR HOUSING
2	OUTER FLANGE	37	SCREW M5×25
3	INLET FLANGE	38	REAR COVER
4	CIRCLIP Φ37	39	SCREW ST4.2×14-F
5	SCREW M4×8	40	SCREW M5×45
6	KNOB	41	PARAMETER LABEL
7	ADJUSTABLE GUARD	42	CARBON BRUSH
8	TENSION SPRING Φ5.2×Φ0.7×88	43	DISC SPRING
9	FLAT WASHER 39×43×1.2	44	CARBON BRUSH HOLDER
10	PLASTIC SLEEVE	45	SCREW ST2.9×8-F
11	OUTPUT SHAFT	46	LEFT HANDLE
12	SCREW M4×10	47	SWITCH
13	FRONT COVER	48	CAPACITOR
14	BEARING 6001-2RS	49	CABLE PRESS PLATE
15	CIRCLIP Φ28	50	RIGHT HANDLE
16	LOCATING STEEL SLEEVE	51	CABLE SHEATH
17	WOODRUFF KEY 3×10	52	POWER CABLE
18	LARGE GEAR	53	LOCKING KNOB ASSEMBLY
19	CIRCLIP Φ10	54	FLAT WASHER 6×14×1.5
20	BEARING 606-2Z	55	ANGLE ADJUSTMENT BRACKET
21	RUBBER COLUMN Φ4×7	56	NUT M4
22	HEAD HOUSING	57	SCREW M4×10
23	SCREW M5×18	58	BOLT M6×14
24	LOCATING RING	59	RIVET 5×7
25	FLAT WASHER 6×20×1.5	60	BASE PLATE
26	SPRING DOWEL PIN 6×35	61	SCREW M6×16
27	BEARING 6000-2RS	62	DEPTH ADJUSTMENT BRACKET
28	COMPRESSION SPRING Φ7.3×Φ0.7×33	63	NUT M6×6.5
29	SELF-LOCKING PLATE	64	LOCKING KNOB
30	ROTOR	65	CLAMPING KNOB
31	BEARING 607-2RS	66	COMPRESSION SPRING Φ8.2×Φ0.8×3
32	BEARING BUSH	67	DUST ADAPTER
33	WIND SHIELD	68	SAW BLADE 185×20×2.4×24T
34	SCREW ST4.2×60-F	69	GUIDE
35	STATOR	70	HEX.WRENCH 6