


SturmmaxD

CCM9921CR



NO.	DESCRIPTION	NO.	DESCRIPTION
1	COMPRESS KNOB	30	BEARING 608Z
2	LOCK BLOCK	31	CIRCLIP $\Phi 6$
3	PIN $\Phi 2.5 \times 43$	32	CHAIN WHEEL
4	TENSIONING KNOB	33	SPRING
5	SUPPORT PLATE	34	MOTOR GEAR
6	CHAIN COVER	35	MOTOR
7	CIRCLIP $\Phi 5$	36	SCREW ST4X25
8	SEALING RING	37	MOTOR PCB
9	RUBBER RING	38	LEFT HOUSING
10	RIGHT HOUSING	39	WIRE BUCKLE
11	SWITCH TRIGGER	40	HANG ROPE
12	SPRING	41	PIN $\Phi 4 \times 20$
13	SAFETY LOCKING BUTTON	42	CONNECTION FOOT
14	SPRING	43	BATTERY PACK HOLDER RIGHT
15	SWITCH	44	BATTERY PACK HOLDER LEFT
16	OIL PUMP COMPONENTS	45	SCABBARD
17	OIL TANK	46	CHAIN
18	FUEL TANK JOINT	47	GUIDE BAR
19	OIL SEALING RING	48	SPRING
20	CHECK VALVE	49	OIL TUBING
21	HOOK	50	MOTOR BRACKET RIGHT
22	OIL TANK COVER	51	MOTOR BRACKET LEFT
23	KNOB	52	SCREW ST4X45
24	SEALING RING	53	HANDLE GUARD
25	PIN $\Phi 2.5 \times 30$	54	WARNING BLOCK
26	BEARING 6000RS	55	SCREW ST3X12
27	OUTPUT SHAFT	56	SCREW ST3X8
28	BIG GEAR	57	PRESSURE PLATE
29	TURBINE		

ST-UK250716