



## CCM9940CR

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SWITCH	38	BUMPER SPIKE
2	SWITCH TRIGGER	39	SCREW ST4X40
3	SPRING	40	GUIDE BAR
4	SAFETY LOCKING BUTTON	41	CHAIN
5	SPRING	42	SCABBARD
6	FIXED PLATE	43	SEALING GASKET
7	MOTOR PCB	44	CHAIN COVER
8	SCREW ST4*1 6	45	LOCATING SLEEVE
9	BATTERY PACK HOLDER LEFT	46	COMPRESS KNOB
10	BATTERY PACK HOLDER RIGHT	47	AUXILIARY HANDLE
11	CONNECTION FOOT	48	OIL TANK COVER
12	CONNECTING PIECE	49	SEALING RING
14	REAR COWL	50	POTHOOK
15	LEFT HOUSING	51	CHECK VALVE
16	MOTOR	52	OIL TANK
17	SHAFT SLEEVE	53	FUEL TANK JOINT
18	PINION GEAR	54	SEALING RING
19	NUT M6	55	TUBING
20	GEAR BOX	56	SCREW ST3X8
21	SCREW M5X14	57	OIL PUMP COMPONENTS
22	NUT M8	58	TUBING
23	BEARING 608Z	59	SPRING
24	BIG GEAR	60	SCREW ST4X12
25	SHAFT SLEEVE	61	OUT OF THE NOZZLE
26	BRAKE TORSION SPRING	62	O-RING
27	OUTPUT SHAFT	63	PROTECTIVE PLATE
28	BEARING 6000RS	64	WASHER $\Phi 4 \times \Phi 16$
29	RIGHT HOUSING	65	BRAKE PLATE
30	TENSIONING KNOB	66	LOCATING SLEEVE
31	TENSIONING KNOB SEAT	67	TORSIONAL SPRING
32	SCREW ST4X20	68	SWITCH
33	FAST TENSIONING ASSY	69	WASHER $\Phi 5$
34	CHAIN WHEEL	70	LOCK CATCH
35	SPRING	71	SPRING
36	CIRCLIP $\Phi 7$	72	HANDLE HOLDER
37	Rubber ring		

ST-UK240329