



**CCM9941CRP**

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SWITCH	33	E CIRCULIP
2	SWITCH TRIGGER	34	SEAL RING
3	TRIGGER SPRING	35	OIL PLATE
4	SAFETY ROD	36	TAPPING SCREW ST4X40
5	SPRING	37	GUIDE BAR
6	LED BOARD	38	SAW CHAIN
7	CONTROL PCB	39	BAR COVER
8	TAPPING SCREW ST4X16	40	SEAL RING
9	LEFT BATTERY PACK SEAT	41	SIDE COVER
10	RIGHT BATTERY PACK SEAT	42	POSITION BUSH
11	BATTERY CONNECTION SEAT	43	TIGHEN KNOB
12	CONNECTION PIECE	44	AUXILIARY HANDLE
13	REAR COVER	45	OIL COVER
14	LEFT HOUSING	46	OIL COVER SEAL RING
15.1	REAR MOTOR SUPPORT	47	OIL COVER CONNECTION LINE
15.2	WAVE WASHER	48	VALVE
15.3	BEARING 608	49	OIL TANKD
15.4	ROTOR	50	OIL TANK CONNECTOR
15.5	STATOR	51	OIL TANK SEAL RING
15.6	FRONT MOTOR SUPPORT	52	OIL TUBE
16	MOTOR BUSH	53	TAPPING SCREW ST3X8
17	PINION	54	OIL PUMP
18	NUT M6	55	OIL TUBE
19	MUT M8	56	OIL TUBE SPRING
20	BIG GEAR	57	TAPPING SCREW
21	BUSH	58	OIL OUTLET NOZZLE
22	TWIST SPRING	59	SEAL RING
23	SPINDLE	60	GUARD
24	BEARING 6000	61	WASHER C5X C15X1.5MM
25	RIGHT HOUSING	62	BRAAKER BOARD
26	ADJUST KNOB	63	POSITION BUSH
27	ADJUST POSITIONING SLEEVE	64	BRAAKER BOARD SPRING
28	TAPPING SCREW ST4X20	65	SWITCH
29	TAPPING SCREW ST4X55	66	WASHER
30	ADJUST ROD	67	LOCKING CATCH
31	CHAIN WHEEL	68	SPRING
32	TENSION SPRING	69	HANDLE FIXED BASE

ST-UK251211-1