


CSM5002CR



NO.	DESCRIPTION
1	FLANGE SCREW
2	OUTTER FLANGE
3	SAW
4	INNER FLANGE
5	SPIRAL RETAINING RING
6	SCREW ST4X16
7	HANDLE
8	SHIELD
9	SPRING
10	SCREW M5X25
11	HOUSING
12	STATOR
13	AIR DIRECTOR
14	SCREW ST3.6X16
15	BEARING SLEEVE 607
16	ARMATURE
17	SHAFT LOCKING PLATE
18	O RING
19	SPRING
20	GEAR BOX
21	RUBBER COLOMNN
22	SCREW M4X10
23	BEARING 607
24	BIG GEAR
25	CIRCLIP FOR HOLE
26	WAVE WASHER
27	BEARING 6001
28	GEAR BOX COVER
29	SPINDLE
30	SCREW M4X16
31	HANDLE
32	LAMP COVER
33	RUBBER COLOMNN
34	PIN SEAT
35	BRUSHLESS CONTROLLER
36	SWITCH
37	LOCK BOTTON
38	TRIGGER
39	SCREW ST3X12
40	KNOB
41	NUT M6
42	WASHER
43	NUT M6
44	DEPTH ADJUSTING COD
45	SCREW
46	M6 SCREW
47	BASE PLATE