


EKM8340CR



NO.	DESCRIPTION	NO.	DESCRIPTION
1	TRANSPARENT COVER	42	PROTECT COVER
2	LONG ROUND PIN	43	SCREW M6X25
3	TRANSPARENT COVER TORSION SPRING	44	TRANSMISSION ASSEMBLY
4	SPRING	45	LATCH PIN
5	SHORT ROUND PIN	46	RIGHT BLADE ASSEMBLY
6	SCREW ST4*16	47	LEFT BLADE ASSEMBLY
7	BATTERY CASE	48	RIGHT SINGLE BLADE ASSEMBLY
8	LEFT DECORATION BOARD	49	LEFT SINGLE BLADE ASSEMBLY
9	LOWER HOUSING BODY	50	LEFT WHEEL COVER
10	RIGHT-SIDE COVER TRIM PANEL	51	SPLIT PIN
11	SCREW ST4*8	52	WHEEL
12	LEFT BATTERY CASE COVER	53	WHEEL AND AXLE ASSEMBLY
13	LEFT PLUG-IN COVER	54	FLAT WASHER
14	PLUG-IN SOCKET	55	BUSH
15	RIGHT-SIDE PLUG-IN COVER	56	BOLT M6X35
16	RIGHT BATTERY CASE COVER	57	PULL TAB
17	PRESSING BUTTON	58	ADJUSTABLE MOUNTING BRACKET
18	NUT	59	SELF-LOCKING SPRING
19	PRESSING PLATE	60	ADJUSTING PIN
20	U-TUBE	61	SCREW ST4*16
21	BOLT M6X45	62	RIGHT WHEEL COVER
22	SMALL WIRE CLIP	63	SWITCH BOX COVER
23	FRONT BEND PIPE ASSEMBLY	64	NON-SELF-LOCKING BUTTON
24	BOLT M6X35	65	BUTTON SPRING
25	SCREW ST4*40	66	BATTERY LEVEL DISPLAY PANEL
26	MOTOR ASSEMBLY	67	DISPLAY PANEL COVER
27	GEARBOX COVER	68	TRIGGER SPRING
28	BUSH	69	TRIGGER STOP SLEEVE
29	SMALL GEAR	70	SWITCH
30	NUT M6	71	SCREW 4X12
31	BEARING 608	72	PRESSURE PLATE
32	BEARING 607	73	CABLE
33	BIG GEAR	74	BEND HANDLE
34	PCB	75	SWITCH TRIGGER
35	BEARING 6001	76	HANDLE SPONGE COVER
36	CIRCLIP	77	LOWER COVER FOR SWITCH BOX
37	KEY	78	SCREW 4X16
38	OUTPUT SHAFT	79	SCREW 4X20
39	SHAFT COUPLING SLEEVE	80	LIMIT PLATE COVER
40	MOTOR MOUNTING BASE	81	TRIGGER TORSION SPRING
41	FLEXIBLE SHAFT	82	LOWER COVER OF LIMIT PLATE

EKM8340CR-EX-UK260923-2