




GBEM2241CR

NO.	DESCRIPTION
1	SUCTION FRONT DUCT
2	SUCTION DUCT
3	SUCTION REAR PIPE
4	AIR INLET HOOD
5	LEFT CASING COVER
6	SWITCH
7	SWITCH PUSH BUTTON
8	ROTATING CIRCLE
9	AIR DUCT BUTTON
10	SPRING
11	LEFT CASING
12	SCREWS
13	GASKET
14	BLADE
15	FAN
16	RIGHT CASING
17	SCREW
18	AXLE SLEEVE
19	MOTOR COMPONENTS
20	SELF TAPPING SCREW
21	RIGHT CASING COVER
22	STRAP HOOK
23	RIGHT HANDLE
24	PANEL
25	SCREW
26	ANTI STATIC GUIDE PLATE
27	CONTROLLER COMPONENTS
28	UPPER BATTERY HOLDER
29	INSERT HOLDER ASSEMBLY
30	LOWER BATTERY HOLDER
31	LEFT HANDLE
32	BLOWING FLAT MOUTH
33	BLOWPIPE
34	BLOWING AIR DUCT
35	FRONT HANDLE
36	SUPPORT SEAT
37	DUST BAG SLEEVE
38	DUST COLLECTION BAG
39	HANDLE BUTTON
40	SPRING
41	FRONT HANDLE BUTTON
42	SPRING
43	SPRING
44	BATTERY DISPLAY BOARD
45	NORMALLY CLOSED MICROSWITCHES

GBEM2241CR-EX-UK250530-1