


GM2520CR



NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	17	HOUSING
2	HOLDER ASSY	18	BATTEY BASE(LEFT)
2-1	HOLDER	20	ROUND PIN
2-2	NEEDLE	21	TRIP CONNECTION
2-3	RIVET	22	TRIGGER SPRING
3	SCREW	23	SWITCH TRIGGER
4	TRAY	24	TRIGGER LOCK BLOCK
5	SCREW	25	BATTEY BASE(LEFT)
6	PLATE	26	SCREW
7	FIXED BASE	27	SCREW
8	SCREW	28	HOOK ASSY
9	NUT	28-1	PIN
10	GEARBOX ASSY	28-2	FLAT WASHER
10-1	SCREW	28-3	HOOK HOLDER
10-2	GEAR BOX	28-4	SPRING
10-3	SMALL BEVEL GEAR	28-5	POWDER METALLURGY ACTIVE BLOCK
10-4	SCREW	28-6	HOOK
10-5	BEARING PLATE	29	SPEED CONTROLLER ASSY
10-6	628 BEARING	29-1	SPEED BUTTON
10-7	MIDDLE COVER	29-2	SPEED CONTROLLER
10-8	MIDDLE SHAFT	29-3	MICRO SWITCH
10-9	FIXED INNER RING GEAR	29-4	CIRCUIT BOARD
10-10	PLANET GEAR	29-5	BATTERY PIN
10-11	PLANET WHEEL SHELF	29-6	HALL CIRCUIT BOARD
10-12	RING GEAR	29-7	HALL CELL
10-13	SCREW	30	SPEC. LABEL
10-14	GEAR BOX FOR PLANET	31	BRAND LABEL
10-15	MIDDLE GEAR		
10-16	MOTOR		
10-17	ANTI-FRICTION GASKET		
10-18	BIG BEVEL GEAR		
10-19	ROUND PIN		
11	RACK BAR		
12	RACK BAR SLEEVE ASSY		
12-1	RUBBER SLEEVE		
12-2	SLEEVE OF RACK BAR		
12-3	SPRING		
13	RACK BAR HOLDER ASSY		
13-1	RACK BAR HOLDER		
13-2	MAGANIC		
14	SCREW		
15	TRIP PRESS PLATE		
16	TRIP SPRING		