


GTM3520CR



NO.	DESCRIPTION
1	SCREW 4*16
2	LEFT HANDLE
3	PCB
4	PLUG SOCKET
5	RIGHT HANDLE
6	ANTI-SELF-LOCKING PUSH BUTTON
7	PUSH ROD SPRING
8	TRIGGER SPRING
9	SWITCH TRIGGER
10	MICROSWITCH
11	WIRE PRESS PLATE
12	SCREW 4*14
13	SWITCH PRESSURE SPRING
14	ROTARY LOCATING SLEEVE
15	ROTARY KNOB
16	ROTATING FIXED SLEEVE
17	BIG TUBE
18	SCREW 4*6
19	AUXILIARY HANDLE
20	FRONT HANDLE BUTTON
21	FRONT HANDLE BUTTON SPRING
22	HANDLE BUTTON
23	PIPE SLEEVE
24	CONNECTING SLEEVE
25	BOLT M5X16
26	BOLT M5X30
27	NUT M5
28	PRESS KNOB
29	LOCATION PIN
30	SPRING WIRE
31	SMALL TUBE
32	INDUCTANCE
33	MOTOR
34	MOTOR MOUNTING PLATE
35	SCREW M4X10
36	MOTOR BUSHING
37	LEFT ROTATED COVER
38	SPOOL SPRING
39	ROTATED BUTTON
40	SCREW ST3X8
41	HOUSING
42	LEFT DECORATIVE COVER
43	WHEEL BRACKET
44	WHEEL
45	SHAFT RETAINING RING
46	AXLE
47	WHEEL BRACKET FIXING PLATE
48	SPOOL
49	HOLLOW RIVET
50	BALL
51	BALANCING SPRING
52	NYLON LINE
53	SPOOL COVER
54	NUT M5
55	BALANCE BLOCK
56	WINDING REEL
57	RIGHT ROTATED COVER
58	LOCK PLATE
59	PROTECTIVE WIRE
60	SMALL BLADE
61	PROTECTIVE GRASS BOARD