
GTM3521CR



NO.	DESCRIPTION
1	LEFT AND RIGHT HANDLE HOUSING
2	CASING
3	SHELL FIX COVER
4	GUARD
5	COVER PLATE
6	SWITCH LOCK BUTTON
7	SWITCH TRIGGER
8	ADJUST THE LOCK BUTTON
9	AUXILIARY HANDLE
10	TELESCOPIC PIPE
11	SWITCH
12	BRUSHLESS MOTOR
13	CONTROLLER
14	LARGE GEAR
15	MOTOR GEAR
16	OUTPUT SHAFT
17	BALL BEARING6002RS
18	BALL BEARING698RS
19	SPRING WIRE
20	POWER PLUG
21	LOCK BUTTON SPRING
22	TRIGGER SPRING
23	SCREW ST4*16
24	SCREW ST3*12
25	SCREW ST4*12
26	PRESSURE PLATE ASSEMBLY
27	ANTI-LOOSENING NUT
28	SAW BLADE
29	ANGLE BUTTON
30	ANTI-COLLISION RING

GTM3521CR-EX-UK261102-1

Sturmax