




GTM3541CR

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CABLE CLAMP	41	BEARING 6002
2	SCREW ST4X16	42	LEFT MOTOR HOUSING
3	PCB	43	RIGHT MOTOR HOUSING
4	HOUSING	44	LOWERING PLATE
5	INDICATOR PANEL	45	PROTECTIVE COVER
6	POWER INDICATOR	46	SCREW ST5X14
7	SELF-LOCKING BUTTON	47	SMALL COVER OF PROTECTIVE COVER
8	PUSH-PULL SPRING	48	SCREW M4X8
9	LEFT HANDLE	49	PROTECTIVE COVER BASE
10	MICRO SWITCH	50	SMALL BLADE
11	SWITCH SPRING	51	SPACER WASHER
12	SWITCH TRIGGER	52	UPPER PRESSURE PLATE
14	RIGHT HANDLE	53	3T BLADE PROTECTIVE COVER
15	FRONT ALUMINUM PIPE	54	NUT M10 LEFT
16	HEXAGON LOCKNUT	55	BELT
17	HOOK	56	SPRING WIRE
18	HANGER RING	57	CONNECTING LINE 3
19	SCREW M5X16	58	ALLEN KEY
20	ALUMINUM CONNECTOR	59	SOCKET WRENCH
21	SCREW M5*12	60	SPOOL
22	REAR ALUMINUM PIPE	61	3T BLADE
23	KNOB	62	LOWER BATTERY HOLDER
24	BOLT M6X45	63	SOCKET
25	GEAR LEVER	64	LEAD WIRE
26	D HANDLE	65	TERMINAL CONNECTION WIRE 1
27	NUT M6	66	UPPER BATTERY HOLDER
28	MOTOR COVER	67	SCREW ST4X16
29	STATOR	68	TERMINAL CONNECTION WIRE 2
30	WIND DEFLECTOR		
31	BEARING 606		
32	ROTOR		
33	BEARING 608		
34	SMALL GEAR		
35	ALUMINUM BRACKET		
36	BEARING 607		
37	SHAFT RETAINING RING		
38	BIG GEAR		
39	SPLINED SHAFT		
40	KEY		

GTM3541CR-EX-UK250905-1