

RSM8820CL

NO.	DESCRIPTION	NO.	DESCRIPTION
1	MOTOR	25	RECIPROCATING ARM
2	SCREW M3X12	26	BIG WASHER Ø5.2XØ10X1
3	MOTOR SUPPORT	27	SCREW M5X10
4	SCREW M4X12	28	BASE PLATE
5	MOTOR GEAR	29	CONNECTION BRACKET
6	SCREW M3X6	30	INDUCTOR
7	BEARING PRESS BOARD	31	SWITCH
8	GASKET Ø14XØ16.8X0.9	32	SAFETY LEVEL
9	BEARING 6002Z	33	SPRING
10	GEAR	34	LED
11	PINION	35	LED LIGHT COVER
12	GEAR BOX	36	SCREW M5X12
13	BEARING 608Z	37	TAPPING SCREW ST3X8
14	CIRCLIP 22	38	ALLEN KEY HOLDER
15	BEARING 6000Z	39	ANTI-VIBRATION WASHER
16	WASHER Ø16.5XØ10.2X0.8	40	ANTI-VIBRATION RING
17	BIG GEAR	41	RUBBER BLOCK
18	SPINDLE	42	SQUARE RUBBER BLOCK
19	PIN Ø5X18	43	SEAL
20	BUSH Ø5XØ10X8	44	HOUSING
21	SEAL WASHER	45	TAPPING SCREW ST4X16
22	MIDDLE BOARD	47	RUBBER PIN
23	GEAR BOX COVER	48	RUBBER BLOCK
24	UPPER COVER		

ST-UKW210806