


## SGM9620CRB



NO.	DESCRIPTION
1	SCREW ST3*14
2	RIGHT BOTTOM SEAT
3	HOUSING
4	MAGNET
5	CONNECTION FOOT
6	DECORATIVE BLOCK
7	REAR COVER
8	SCREW ST3.5*6
9	DUSTPROOF SPONGE
10	MOTOR SEAT COVER
11	O-RING
12	MOTOR ASSEMBLY
13	WIRE PROTECTOR
14	MOTOR SEAT
15	LEFT BOTTOM SEAT
16	COVER PLATE LABEL
17	COVER PLATE
18	SPEED CONTROL PCB
19	SCREW ST3*6
20	ADJUST KNOBS
21	ADJUST KNOBS SPRING
22	TRIGGER
23	ADJUST KNOBS PIN
24	O-RING
25	GUN SEAT
26	SPRING
27	O-RING
28	VALVE NEEDLE
29	NOZZLE Ø2.0
30	AIR CAP
31	UNION NUT
32	O-RING
33	PREVENT BACKFLOW GASKET
34	SUCKER
35	CONTAINER SEALING GASKET
36	CONTAINER
37	NOZZLE CLEANING NEEDLE
38	CLEANING BRUSH
39	VISCOSITY MEASURING CUP
40	NOZZLE Ø1.0
41	NOZZLE Ø1.5
42	NOZZLE Ø3.0
43	CHARGER