




## DHM5030

| NO. | DESCRIPTION                | NO. | DESCRIPTION                    |
|-----|----------------------------|-----|--------------------------------|
| 55  | HANDLE                     | 27  | HEAT INSULATION CASING BRACKET |
| 54  | STEEL PIPE PLUG            | 26  | AIR OUTLET COVER ASSEMBLY      |
| 53  | SCREW NUT                  | 25  | BOTTOM CASING                  |
| 52  | FLAT GASKET                | 24  | IGNITION TRANSFORMER           |
| 51  | WHEEL                      | 23  | FUEL FILTER                    |
| 50  | COTTER PIN                 | 22  | SEALING RING-2                 |
| 49  | FEET PIPE                  | 21  | DISPLAY PCB2                   |
| 48  | WHEEL AXLE                 | 20  | PCB SUPPORT                    |
| 47  | SIDE PLATE                 | 19  | CONTROL PANEL                  |
| 46  | TOP COVER                  | 18  | ON/OFF SWITCH                  |
| 45  | FAN                        | 17  | DISPLAY WINDOW                 |
| 44  | BLADE BASE                 | 16  | THERMOSTAT ADJUSTMENT KNOB NUT |
| 43  | MOTOR ASSEMBLY             | 15  | THERMOSTAT KNOB                |
| 42  | MOTOR SUPPORT              | 14  | POWER PCB1                     |
| 41  | AIR INLET GRILL            | 13  | OIL DRAIN SCREW                |
| 40  | IGNITION NEEDLE            | 12  | OIL DRAIN SEAL RING            |
| 39  | OIL HOSE                   | 11  | FUEL TANK                      |
| 38  | GAS HOSE                   | 10  | CABLE FASTENER                 |
| 37  | NOZZLE ADAPTER             | 9   | POWER CORD                     |
| 36  | NOZZLE ASSEMBLY            | 8   | SUPPORT                        |
| 35  | BURNER HEAD                | 7   | OIL LEVELER                    |
| 34  | PHOTOCELL ASSEMBLY         | 6   | OIL INLET FILTER HOLDER        |
| 33  | PHOTOCELL ASSEMBLY BRACKET | 5   | OIL INLET FILTER               |
| 32  | RE-SET THERMOSTAT          | 4   | TANK CAP SHAFT                 |
| 31  | PHOTOCELL ASSEMBLY BRACKET | 3   | SEALING RING-1                 |
| 30  | BURNER SUPPORT PLATE       | 2   | FUEL TANK CAP                  |
| 29  | COMBUSTION CHAMBER         | 1   | BREATH COVER                   |
| 28  | HEAT INSULATION CASING     |     |                                |