


DHM5030C



NO.	DESCRIPTION	NO.	DESCRIPTION
72	CABLE HOLDER	36	RE-SET THERMOSTAT
71	HANDLE	35	RE-SET THERMOSTAT BRACKET
70	STEEL PIPE PLUG	34	PHOTOCELL ASSEMBLY
69	SCREW NUT	33	AIR ADJUSTMENT RING
68	FLAT GASKET	32	PHOTOCELL ASSEMBLY BRACKET
67	WHEEL	31	HOOK
66	COTTER PIN	30	COMBUSTION CHAMBER
65	FEET PIPE	29	CHAMBER BRACKET
64	WHEEL AXLE	28	HEAT INSULATION CASING
63	SIDE PLATE	27	AIR OUTLET
62	CHIMNEY CONNECTOR	26	BOTTOM CASING
61	TOP FRONT COVER	25	POWER PCB1
60	TOP BACK COVER	24	PCB SUPPORT
59	FAN	23	CONTROL PANEL
58	MOTOR	22	ON/OFF SWITCH
57	SOLENOID VALVE CORD	21	DISPLAY PCB2
56	GEAR PUMP AXLE SLEEVE	20	DISPLAY WINDOW
55	GEAR PUMP	19	THERMO CUT-OFF ADJUST NUT
54	FUEL FILTER JOINT	18	THERMOSTAT KNOB
53	MOTOR SUPPORT	17	OIL LEVELER
52	AIR INLET GRILL	16	OIL INLET FILTER
51	FILTER SUPPORT	15	OIL INLET FILTER HOLDER
50	OIL PIPE 350(L)	14	TANK CAP SHAFT
49	FILTER	13	SEALING RING
48	OIL PIPE 350(LL)	12	FUEL TANK CAP
47	OIL PIPE 300(L)	11	BREATH COVER
46	WIND SHIELD	10	BRACKET OF IGNITION TRANSFORMER
45	HIGH VOLTAGE CABLE	9	IGNITION TRANSFORMER
44	OIL TUBE ASSEMBLY	8	OIL RETURN PIPE
43	IGNITION NEEDLE	7	SEALING RING
42	COPPER BEND CONNECTION	6	OIL SUCTION PIPE
41	SCREW NUT	5	CABLE FASTENER
40	NOZZLE BASE PLATE	4	POWER CORD
39	SWIRL DISC	3	FUEL TANK
38	NOZZLE ADAPTER	2	OIL DRAIN SCREW
37	NOZZLE ASSEMBLY	1	OIL DRAIN SEAL RING