


## DHM5050C



| NO. | DESCRIPTION        | NO. | DESCRIPTION             |
|-----|--------------------|-----|-------------------------|
| 74  | CABLE HOLDER       | 37  | THERMOSTAT BRACKET      |
| 73  | HANDLE             | 36  | PHOTOCELL ASS'Y         |
| 72  | STEEL PIPE PLUG    | 35  | AIR ADJUSTMENT RING     |
| 71  | SCREW NUT          | 34  | PHOTOCELL ASS'Y BRACKET |
| 70  | FLAT GASKET        | 33  | HOOK                    |
| 69  | WHEEL              | 32  | COMBUSTION CHAMBER      |
| 68  | COTTER PIN         | 31  | CHAMBER BRACKET         |
| 67  | FEET PIPE          | 30  | CASING SUPPORT RING     |
| 66  | WHEEL AXLE         | 29  | HEAT INSULATION CASING  |
| 65  | SIDE PLATE         | 28  | AIR OUTLET CONE         |
| 64  | CHIMNEY CONNECTOR  | 27  | THERMOSTAT KNOB         |
| 63  | TOP FRONT COVER    | 26  | FIXING NUT              |
| 62  | TOP BACK COVER     | 25  | DISPLAY WINDOW          |
| 61  | FAN                | 24  | DISPLAY PCB2            |
| 60  | MOTOR              | 23  | ON/OFF SWITCH           |
| 59  | VALVE CORD         | 22  | SUPPORT BRACKET         |
| 58  | PUMP COUPLING      | 21  | CONTROL PANEL           |
| 57  | GEAR PUMP          | 20  | PCB SUPPORT             |
| 56  | FUEL PIPE JOINT    | 19  | POWER PCB1              |
| 55  | MOTOR SUPPORT      | 18  | IGNITION TRANSFORMER    |
| 54  | AIR INLET GRILL    | 17  | BODY SUPPORT PIPE       |
| 53  | FILTER SUPPORT     | 16  | BOTTOM CASING           |
| 52  | OIL PIPE 350(L)    | 15  | OIL PIPE UNION          |
| 51  | FILTER             | 14  | SEALING RING            |
| 50  | OIL PIPE 350(LL)   | 13  | OIL SUCTION PIPE        |
| 49  | OIL PIPE 400(L)    | 12  | BREATH COVER            |
| 48  | AIR BALANCE PLATE  | 11  | FUEL TANK CAP           |
| 47  | HIGH VOLTAGE CABLE | 10  | SEALING RING            |
| 46  | OIL TUBE ASSEMBLY  | 9   | TANK CAP SHAFT          |
| 45  | IGNITION NEEDLE    | 8   | OIL INLET FILTER        |
| 44  | ELBOW CONNECTION   | 7   | OIL INLET FILTER HOLDER |
| 43  | SCREW NUT          | 6   | OIL LEVELER             |
| 42  | NOZZLE BASE PLATE  | 5   | CABLE FASTENER          |
| 41  | SWIRL DISC         | 4   | POWER CORD              |
| 40  | NOZZLE ADAPTER     | 3   | FUEL TANK               |
| 39  | NOZZLE ASS'Y       | 2   | OIL DRAIN SEALING RING  |
| 38  | RE-SET THERMOSTAT  | 1   | OIL DRAIN SCREW         |