


DHM5080C



NO.	DESCRIPTION	NO.	DESCRIPTION
74	CABLE HOLDER	37	THERMOSTAT BRACKET
73	HANDLE	36	PHOTOCELL ASS'Y
72	STEEL PIPE PLUG	35	AIR ADJUSTMENT RING
71	SCREW NUT	34	PHOTOCELL ASS'Y BRACKET
70	FLAT GASKET	33	HOOK
69	WHEEL	32	COMBUSTION CHAMBER
68	COTTER PIN	31	CHAMBER BRACKET
67	FEET PIPE	30	CASING SUPPORT RING
66	WHEEL AXLE	29	HEAT INSULATION CASING
65	SIDE PLATE	28	AIR OUTLET CONE
64	CHIMNEY CONNECTOR	27	THERMOSTAT KNOB
63	TOP FRONT COVER	26	FIXING NUT
62	TOP BACK COVER	25	DISPLAY WINDOW
61	FAN	24	DISPLAY PCB2
60	MOTOR	23	ON/OFF SWITCH
59	VALVE CORD	22	SUPPORT BRACKET
58	PUMP COUPLING	21	CONTROL PANEL
57	GEAR PUMP	20	PCB SUPPORT
56	FUEL PIPE JOINT	19	POWER PCB1
55	MOTOR SUPPORT	18	IGNITION TRANSFORMER
54	AIR INLET GRILL	17	BODY SUPPORT PIPE
53	FILTER SUPPORT	16	BOTTOM CASING
52	OIL PIPE 350(L)	15	OIL PIPE UNION
51	FILTER	14	SEALING RING
50	OIL PIPE 350(LL)	13	OIL SUCTION PIPE
49	OIL PIPE 400(L)	12	BREATH COVER
48	AIR BALANCE PLATE	11	FUEL TANK CAP
47	HIGH VOLTAGE CABLE	10	SEALING RING
46	OIL TUBE ASSEMBLY	9	TANK CAP SHAFT
45	IGNITION NEEDLE	8	OIL INLET FILTER
44	ELBOW CONNECTION	7	OIL INLET FILTER HOLDER
43	SCREW NUT	6	OIL LEVELER
42	NOZZLE BASE PLATE	5	CABLE FASTENER
41	SWIRL DISC	4	POWER CORD
40	NOZZLE ADAPTER	3	FUEL TANK
39	NOZZLE ASS'Y	2	OIL DRAIN SEALING RING
38	RE-SET THERMOSTAT	1	OIL DRAIN SCREW