



ESM1028BL

NO.	DESCRIPTION
1	CAPACITANCE
2	UPPER HOUSING ASSEMBLY
3	PUSH STICKER
4	SWITCH ASSEMBLY
5	PLUG BOX ASSEMBLY
6	MOTOR ASSEMBLY
7	FLAT KEY
8	KNOB
9	O-RING
10	REGULATING PLATE
11	BLADE
12	BLADE BOX ASSEMBLY
13	AIR WINDOW
14	SCREW ST4x20
15	ALLEN WRENCH
16	SCREW ST6x25
17	COLLECTOR BOX ASSEMBLY
18	SUPPORTING TUBE ASSEMBLY
19	WHEEL COVER
20	R PIN
21	WASHER Ø10
22	WHEEL
23	WHEEL SHAFT SLEEVE
24	WHEEL SHAFT
25	FOOT PAD
26	SCREW ST5x45

UK240507-1