



IDM2155P

NO.	DESCRIPTION	NO.	DESCRIPTION
1	KEYLESS CHUCK	30	MOTOR FLANGE
2	ADJUSTMENT PLATE	31	DUST PROOF WASHER
3	INTERNAL SCREW SLEEVE	32	BALL BEARING 6000Z
4	BIG SPRING	33	STATOR
5	BIG WASHER	34	ROTOR
6	OUTPUT SHAFT	35	INSULATING BARRIER
7	WASHER	36	BALL BEARING 607Z
8	BALL BEARING 6800Z	37	BRUSH CAP
9	STEEL BALL $\Phi 5$	38	CARBON BRUSH
10	GEAR CASE	39	BRUSH HOLDER
11	BALL BEARING 6800Z	40	CARBON BRUSH HOLDER
12	CIRCLIP $\Phi 10$	41	SPEED PUSH BUTTON
13	FIXED RING	42	SPEED SPRING
14	ROUND PIN	43	ROUND PIN
15	DRIVING DISC	44	ADJUSTMENT PLATE SHRAPNEL
16	LEVEL 3 PLANET CARRIER	45	TENSION SPRING
17	INNER GEAR RING	46	INDUCTANCE
18	LEVEL 3 PLANETARY GEAR	47	DIRECTION SETTING BUTTON
19	WASHER	48	SWITCH
20	LEVEL 2 PLANET CARRIER	49	CAPACITOR
21	HOOK	50	CORD ANCHORAGE
22	SPEED CHANGING BOX	51	TAPPING SCREW ST4*14
23	TAPPING SCREW ST3*12	52N	CABLE
24	DYNAMIC GEAR RING	53	HOUSING ASSEMBLY
25	LEVEL 2 PLANETARY GEAR	54	TAPPING SCREW ST3*14
26	LEVEL 1 PLANET CARRIER	55	CHUCK SCREW
27	LEVEL 1 PLANETARY GEAR	56	SPRING
28	FIXED GEAR RING	57	CABLE GUARD
29	CLAMP	100	GEAR BOX ASSEMBLY

UK-ST20210428