


IDM2190



NO.	DESCRIPTION
1	LEFT SCREW
2	CHUCK
3	SPINDLE
4	SPRING
5	BEARING 6001Z
6	CIRCLIP
7	BIG GEAR
8	NEEDLE BEARING HK0808
9	IMPACT/DRIL CHANGE BUTTON
10	IMPACT/DRIL CHANGE PLATE
11	CENTRAL SUPPORT
12	BEARING 608RS
13	ROTOR
14	STATOR
15	BRUSH HOLDER
16	CARBON BRUSH
17	BRUSH COVER
18	BEARING 627Z
19	HOUSING
20	INDUCTANCE 1
21	INDUCTANCE 2
22	DIRECTION POLE
23	SWITCH
24	CAPACITOR
26	CABLE SLEEVE
27	CABLE
28	SCREW
30	HANLDE BOLT
31	HANDLE CLMAP
32	HANDLE
33	DEPTH RULER