

PCM8806DKW

NO.	DESCRIPTION	NO.	DESCRIPTION
1	THE FOAM OF HANDLE GRIP	45	ENGINE AMOUNTING PLATE
2	HANDLE	46	FLAT WASHER 10N
3	CORD SWITCH	47	HEX NUT M10
4	SNAP-HEAD BOLT	48	HEX BOLT M6X16
5	HEX-NUT M6	49	SPRING WASHER 6
6	SPRING PIN	50	RIGHT BEARING COVER
7	CAP NUT	51	SEAL RING
8	TENSION SPRING	52	BEARING 6209
9	PIPE END CAP	53	CIRCLIP FOR HOLE 100
10	HEX SUNK SCREW M8X20	54	VIBRATION SHAFT
11	HEX BOLT M6X40	58	LEFT BEARING COVER
12	FLAT WASHER 6N	59	LIP OIL SEAL 30X42X7
13	HOOK	60	FLAT WASHER 6 X 6 X 20
14	CONNECTION FRAME FOR HANDLE	61	PULLEY
15	HEX BOLT M10X65	62	PULLEY CIRCLIP
16	SHOCK-REDUCING RUBBER RING	63	BOTTOM PLATE
17	SELF-LOCKING NUT	64	SHOCK-REDUCING RUBBER BLOCK
18	RUBBER GASKET	65	HEX FLANGE NUT M10
19	SEAL RING 5	66	END NUT
20	PETROL ENGINE	67	WASHER
21	HEX FLANGE NUT M8	68	SPLIT PIN 2.5 X 25
22	FIXED PLATE FOR BOLT	69	FLAT WASHER 14N
23	ASJUSTING WASHER	70	5" WHEEL
24	OIL DRAIN PIPE	71	HEX SELF-LOCKING NUT M12
25	CLUTCH SPRING	72	HEX BOLT M10X30
26	CLUTCH FRICTION BLOCK	73	CONNECTION ROD
27	CLUTCH CORE	74	TRANSPORT FRAME
28	CLUTCH BELT PULLEY	75	HEX BOLT M12X25
29	BEARING 6006-LS	76	RUBBER PAD
30	CIRCLIP FOR SHAFT 30	77	RUBBER PAD SPLINT
31	CIRCLIP FOR HOLE 55	78	HEX BOLT M10 X 35
32	FLAT WASHER 8N	79	THROTTLE WIRE+THROTTLE CABLE
33	SPRING WASHER 8	101	OUTLET PIPEWORK
34	HEX BOLT M8X25	102	HEX BOLT M8X20
35	FIXED PLATE BELT COVER	103	VALVE
36	V-BELT	104	PIPE CLAMP
37	BELT COVER	105	WATER PIPE
38	FLAT WASHER 8N	106	WATER TANK COVER
39	HEX NUT M10	107	WATER TANK
40	HEX NUT M8	108	WATER TANK FRAME
41	HEX BOLT M8X16		
42	SHOCK-REDUCING RUBBER BLOCK		
43	RUBBER BLOCK		
44	HEX BOLT M8X60		

