



PWM9213I



NO.	DESCRIPTION	NO.	DESCRIPTION
1	KNDB ASSEMBLY	32	POWER CORD
2	DECORATIVE STRIP	33	TURBO NOZZLE
3	FRONT HOUSING	34	0° NOZZLE
4	WATERPROOF CAP	35	15° NOZZLE
5	SHIFT LEVER	36	25° NOZZLE
6	SWITCH	37	40° NOZZLE
7	SWITCH BOX	38	NOZZLE HOLDER 2
8	MOTOR COVER	39	LEFT PIPE ROLLER SUPPORT
9	VIBRATION DAMPING PAD	40	LEFT SUPPORT FOR THE GUIDE PIPE
10	PUMP BASE	41	RIGHT SUPPORT FOR THE GUIDE PIPE
11	MOTOR+PUMP ASSEMBLY	42	STOP BLOCK
12	CAPACITOR BOX	43	RIGHT PIPE ROLLER SUPPORT
13	CAPACITOR	44	HANDLE
14	CAPACITOR CAP	45	METAL PIPE
15	HIGH PRESSURE HOSE	46	ROLLER HANDLE
16	BOLT M6X20	47	ROLLER CRANK
17	WASHER Ø6	48	ROLLER ROCKER
18	WASHER Ø6	49	RIGHT FLANGE OF THE TUBE ROLLER
19	WHEEL COVER	50	REEL WHEEL HUB
20	WHEEL AXLE	51	LEFT FLANGE OF THE TUBE ROLLER
21	WHEEL	52	CIRCLIP Ø12
22	HOUSING	53	U-PIN
23	WATER INLET CONNECTOR	54	THREE-WAY VALVE SLEEVE
24	CABLE HOOK	55	RUBBER GASKET
25	NOZZLE HOLDER 1	56	O-RING
26	NOZZLE FIXING CAP	57	THREE-WAY VALVE CORE
27	GUN HOLDER	58	O-RING
28	GUN BARREL	59	BOLT M8X10
29	TRIGGER GUN	60	TWO-WAY JOINT ASSEMBLY
30	SOAP BOTTLE HOLDER	61	NOZZLE CLEANING NEEDLE
31	SOAP BOTTLE		

PUMP FOR PWM9213I



NO.	DESCRIPTION
1	CIRCLIP Ø15
2	MOTOR FAN
3	MOTOR
4	WOBBLE PLATE
5	THRUST BEARING 51108
6	Ø6 SPRING WASHER
7	BOLT M6X20
8	BOLT M6X70
9	Ø6 WASHER
10	PUMP HEAD ASSEMBLY
11	BOLT M6X8
12	OULET VALVE ASSEMBLY
13	O-RING
14	CHECK VALVE NUT
15	O-RING
16	PUMP HEAD COVER ASSEMBLY
17	PUMP HEAD COVER
18	WATER SEAL
19	INLET VALVE ASSEMBLY
20	PUMP ASSEMBLY
21	SEALING BASE
22	OIL SEAL
23	BYPASSING VALVE ASSEMBLY
24	PUMP BODY
25	PLUNGER ASSEMBLY
26	O-RING
27	WATER INLET JOINT
28	O-RING
29	U-PIN
30	TOTAL VALVE ASSEMBLY
31	MICRO SWITCH ASSEMBLY
32	SEALING GASKET
33	WATER OUTLET JOINT
34	BUILT-IN HIGH PRESSURE HOSE